SOLAN COLLEGE

## OPERATION AND MAINTENANCE MANUAL

CINEMATRONICS, INC. 1841 FRIENDSHIP DRIVE EL CAJON, CA 92020 (714) 562-7000

**TELEX: CINEMAT ELCJ 697891** 

CALL TOLL FREE: 800 854-2666

**IN CALIFORNIA CALL: 714-562-7000** 

**SALES: 8-5 (PST) WEEKDAYS** 

**SERVICE: 8-5 (PST) WEEKDAYS** 

Copyright 1981 All Rights Reserved

## CINEMATRONICS INC. SOLAR QUEST

#### **WARNING:**

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction's manual, may cause interference to radio communication. As temporarily permitted by regulation it has not been tested for compliance persuant to Subpart J of part 15 of FCC rules, which is designed to provide reasonable protection against such interference. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

#### TABLE OF CONTENTS

Section	Title	Page
PURPO	OSE AND LIMITATIONS OF THIS MANUAL	i
WARR.	ANTY	ii
CUSTO	OMER SERVICE PROCEDURES FOR AUTHORIZED DISTRIBUTORS	iii
	PART ONE	
	Information for Operators	
Section	Title	Page
1	HOW TO PLAY SOLAR QUEST	1-1
2	RECEIVING AND INSTALLING SOLAR QUEST	2-1
3	GENERAL INFORMATION AND PERIODIC MAINTENANCE	3-1
4	OPERATOR'S GUIDE TO TROUBLESHOOTING	4-1
	PART TWO	
	Information for Technicians	
Section	Title	Page
5	VECTORY THEORY	5-1
6	THEORY OF OPERATION	6-1
	A. Monitor	
	B. CPU	
	C. Audio Board	
7	TROUBLESHOOTING	7-1
8	PARTS LIST	8-1

#### APPENDIX A

Assembly Drawings, Schematics, Wiring Diagrams.

#### PURPOSE AND LIMITATIONS OF THIS MANUAL

This manual has 2 major purposes, and is correspondingly separated into 2 major parts.

Part One of the manual contains information operators need to know. It has been written to tell people who have little or no technical knowledge what they should know about this game, without getting technical.

Part Two of this manual is designed to help the qualified technician understand the functions of the various circuits in the game, and quickly troubleshoot any problems. If you need further assistance, please call Cinematronics' Customer Service Department at the toll free number.

THIS MANUAL DOES NOT REPLACE TECHNICAL EXPERTISE. SHOULD OUT-OF-WARRANTY REPAIR BE NECESSARY, WE SUGGEST THE OPERATOR PROTECT HIS/HER INVESTMENT BY HIRING AN EXPERIENCED, COMPETENT TECHNICIAN (PREFERABLY WITH SOME KNOWLEDGE OF THE VECTORBEAM TM\* MONITOR). WE HAVE SEEN MANY EXAMPLES COME INTO THE FACTORY OF INCOMPETENT REPAIR CREATING MANY MORE PROBLEMS THAN ORIGINALLY EXISTED. ONE COMMON FAULT IS INCORRECT SUBSTITUTION OF PARTS. ANOTHER IS DAMAGED FOIL TRACES ON PC BOARDS. REPAIRING BROKEN FOIL IS TIME CONSUMING AND THEREFORE COSTLY.

#### WARRANTY

Cinematronics, Inc. warrants the goods to be free from defects in material and workmanship under normal use and service for a period of ninety (90) days from the date of shipment from factory. Cinematronics makes no representation or warranties concerning the goods whether express or implied by operation of law or otherwise, including those of merchantability or fitness for any particular purpose, or with respect of patent infringement, except as may be specifically made herein. Cinematronics limits its warranty obligations herein to the repair or replacement of such parts which have been returned to Cinematronics' plant at purchaser's expense and which examination shall disclose to Cinematronics' satisfaction to have been so defective and to the shipment of such repaired or replacement parts to the purchaser F.O.B. the shipping point.

This warranty does not apply to any Cinematronics product which has been altered or repaired by unauthorized personnel or service facilities or any products which have had the unit serial number altered or removed.

Upon acceptance of the goods, the purchaser agrees to assume all liability for damages and/or bodily injury by the purchaser or any other person and to hold Cinematronics, Inc. harmless from liability or claims arising from the use of the goods by any person. Purchaser further agrees to indemnify Cinematronics, Inc. from any liability, claim, cause of action or litigation resulting from the use or misuse of the goods by any person.

Parts returned for warranty service must be packaged so that no damage is incurred during the shipment. Full documentation and instructions must accompany returned parts. Parts must be shipped prepaid to:

Cinematronics, Inc. 1841 Friendship Drive El Cajon, CA 92020

#### CUSTOMER SERVICE PROCEDURES

#### FOR AUTHORIZED CINEMATRONICS' DISTRIBUTORS

It is the desire of Cinematronics, Inc., to provide efficient and courteous service should the need arise. We have a fully staffed Customer Service Department and encourage you to call our toll free number: 800-854-2666 for technical assistance between the hours of 8:00 A.M. and 5:00 P.M., California time, Monday through Friday.

In order to provide the very best service possible, the following procedure for ordering or returning parts must be followed:

- 1. All equipment ordered from Customer Service, whether in or out of Warranty, must be placed with a Distributor's purchase order, either by mail or verbally by telephone.
- 2. Advance replacement items may be obtained only during the term of the Warranty and when such items are available, using the same procedure as when ordering parts. When ordering a PCB, please include with your order the game serial number and the number of the PCB you wish replaced.
- 3. All items received as advance replacements will, after a period of thirty (30) days, become the property of the Distributor, with applicable charges applied in the event Customer Service has not received the defective item against which the advance replacement was made.
- 4. The Distributor must call this facility for an RMA number prior to returning any item. Please be prepared to provide us with the game serial number and the PCB number when requesting an RMA.
- 5. In all situations covered above, and in all other situations, the Warranty offered by Cinematronics, Inc., is applicable and should be fully understood.
- 6. Parts returned for service must be packaged so that no damage is incurred during the shipment. Cartons without a prominently displayed RMA number will not be accepted. Full documentation including game serial number, PCB number on outside of package, and reason for return must accompany parts. Ship prepaid to:

Cinematronics, Inc. Customer Service Department 1841 Friendship Drive El Cajon, CA 92020

800-854-2666 714-562-7000

# PART ONE

Information for Operators

#### SECTION 1

## HOW TO PLAY SOLAR QUEST

#### **GAME LAYOUT**

In the center of the screen is a sun. Any space ships or ships' fire coming in contact with the sun are destroyed. The sun exerts an increasing gravitational pull as play progresses.

A player controlled space ship is randomly located on the screen. The space ship's movement is controlled by rotate right, rotate left, and thrust buttons. For quick escapes, the space ship can be thrust into hyperspace, causing the ship to disappear and then reappear in a different location.

The space ship possesses two weapons. The first weapon consists of shots fired by pressing the fire button. These shots will destroy any alien ships they strike, but will disintegrate if they do not hit any targets. The second weapon is a nuke which is launched by pressing the nuke button. The nuke will continue to travel across the screen until either it strikes a target or the player detonates the nuke by pressing the nuke button a second time. The nuke will destroy all alien ships within a limited radius of the explosion.

At the top of the screen is a display showing the player's score, the number of ships remaining, and the number of nukes a player has available.

#### **GAME PLAY**

The game consists of different phases. Each phase begins with several alien ships appearing from random points along the edge of the screen. The number of the alien ships is determined by the phase, with a maximum of eight ships for any single type of alien ship in a phase.

The alien ships move across the screen in a random pattern. After a predetermined time, dependent upon the phase, the alien ships will begin to chase the player's space ship. The player must shoot the alien ships before his ship is rammed by an alien ship. In later phases, the alien ships can shoot at the player's space ship as well as ram it.

Any alien ship that is destroyed by the player will leave a survivor. The player can either capture or kill the survivor. Survivors cannot be killed with nukes. If the survivor is neither captured nor killed, it will begin to drift towards the sun. Survivors disappear when they come in contact with the sun.

If the player does not shoot any alien ships, one or two ghost ships will appear and begin to chase the player's space ship. The ghost ship will shoot at the player's space ship during any phase. The length of time it takes for the ghost ships to appear shortens with each phase, until at least one is always present. A ghost ship will not leave a survivor when it is destroyed.

During a phase, seven different types of alien ships will appear. It is possible for several types of alien ships to be on the screen at one time. A phase is completed after all the alien ships have been destroyed or a specific amount of time has elapsed.

A player must be careful when using hyperspace. Excessive use will cause hyperspace to lock-out for a short period, making a player's space ship more vulnerable. A player's space ship cannot be destroyed in hyperspace.

As play continues, each phase becomes successively more difficult; the number of alien ships increases, the length of time before the alien ships attack shortens, and the alien ships firing capability activates. When a player's space ship is destroyed, play resumes at the same point. The game ends when all of a player's space ships are destroyed.

One and two player options are available. In the two player mode, players alternate until all their ships are destroyed, If one player receives more extra ships than another, he will be allowed to play the extra ships even though his opponent's game is over.

#### **SECTION 2**

## RECEIVING AND INSTALLING SOLAR QUEST

#### RECEIVING INSPECTION

Your game was shipped in ready-to-play condition. However, after removal of the shipping carton, a brief visual examination is suggested.

Naturally, you'll want to make note of any physical damage to the game cabinet and its external components for freight claim purposes. Considering the quality of the shipping carton, any damage to the exterior would indicate possible interior damage as well.

The interior of the game should also undergo a brief examination for: loose mounting hardware (check to be sure that the major components are still securely mounted); disconnected or loose wires, cables or harnesses; electronic devices loose in their sockets; etc.

At this time the game serial number should be logged. Remember that the game serial number will be required if you need service from your distributor. Please complete the postage-free reply card and mail immediately.

#### ELECTRICAL REQUIREMENTS

Unless specified otherwise, your game was shipped to operate at 115 VAC, 50/60 Hz.

A good earth ground is essential for the proper operation of this game or for that matter any electronic device. Problems with instability and erratic operation of computer-type devices can usually be traced to an ineffective ground system. Therefore, plug the game into a properly wired 3 prong outlet. If a 3 prong to a 2 prong AC adaptor must be used, an alternate method of grounding the third prong must be used.

#### **INITIAL ADJUSTMENTS**

#### **NOTE**

When the game is connected to AC power, one of the game sounds may be heard. This is normal.

The audio level (volume) can be easily adjusted and THIS IS ACHIEVED BY ROTATION OF THE VOLUME POT LOCATED ON THE COIN DOOR. The audio level should compete with other machines "on the floor" to maximize play time.

Display brightness is another easy adjustment. Keep the brightness at the correct level for appeal.

#### **OPERATOR OPTIONS**

The option switches allow you to select how many ships per game, how many coins per credit, and a test pattern for the Vectorbeam monitor. The option switch is located on the logic board. The following table will assist you with your selections.

#### SCORING AND BONUSES

	DOMEC
	POINTS
TYPE	SCORED
1st Alien	250
2nd Alien	300
3rd Alien	350
4th Alien	400
5th Alien	450
6th Alien	500
7th Alien	750
Ghost	2500
Survivor Shot	250
Survivor Captured	1000

An extra nuke is awarded every 10,000 points. An extra space ship is awarded after capturing a specified number of survivors.

#### **GAME FEATURES**

- The number of alien ships for any type increases from four phase one to eight in phase five.
- 2. The sun's gravity increases with each phase, starting in phase five.
- 3. The speed of the alien ships increases with each phase.
- 4. Alien ships' firing capability becomes activated in phases five through eleven. The seventh type of alien ship receives firing capability in phase five, the sixth type in phase six, the fifth type in phase seven, and so on, until all the alien ships have firing capability in phase eleven.

- 5. The ghost ships will appear in a shorter amount of time each phase, until at least one is always present.
- 6. The number of captured survivors needed to receive an extra space ship is adjustable, either twenty-five or forty.
- 7. The number of ships per credit is adjustable, either three or five.
- 8. The number of credits per coin is adjustable.

#### **SECTION 3**

## GENERAL INFORMATION AND PERIODIC MAINTENANCE

Your Cinematronics game is designed much the same as conventional video games. The major exception is the use of an alternate means of visual display . . . the patented Vectorbeam tm\* monitoring system. However, the game is built of the same basic building blocks as any other video game.

The Power Supply provides all the necessary voltages for the CPU board, audio board, Vectorbeam monitor and fluorescent light. As you look in the back of the cabinet, it is located on the lower right side of the cabinet. The power supply has two circuit breakers, and a 3 ampere slo-blo fuse. If one circuit breaker trips, the other breaker will soon follow. Always unplug the game before replacing the fuse or resetting the circuit breakers. If you need to replace the fuse use only a 3 amp. slo-blo fuse. The power supply also has a line voltage select switch that must be set to match the voltage in your area. There is also an adjustment for the +5 volt section. DO NOT ADJUST unless you use a volt meter and follow the procedure in Section 6. If needed, this power supply is directly interchangeable with the power supplies used in previous Cinematronics games.

The Central Processing Unit (CPU) is the "brain" of the game. As you look in the back of the cabinet it is the large PC (printed circuit) board on the left side. It "senses" when a coin is dropped in the coin slot, operates the coin meter, and gives credit. It then "reads" what is happening at the operator controls, interprets and computes to make the game play according to what buttons the player pushes. It tells the Vectorbeam monitor what to draw on the screen, and it tells the audio board when to make the appropriate sound effect. The CPU has a red LED (light-emitting diode), near the Molex power plug. This LED normally flashes once when power is turned on, then stays off. More on this in Section 6.

The Audio Board generates all the sound effects for the game and powers the loudspeaker. As you look in the back of the cabinet, it is the smaller PC board on the left side, just below the CPU.

The Vectorbeam tm\* Monitor is the picture tube and associated "Monitor Board." It draws pictures on the picture tube screen according to the instructions it receives from the CPU. If it does not receive correct data from the CPU, it will pop the circuit breakers. The only operator adjustment here is the brightness control. (See display P.C.B. Connectors and Adjustments.)

The Vectorbeam tm\* Monitor is a completely different system from the standard raster-type monitor. Two advantages to this monitor are:

- 1. circuitry is simplied, and
- 2. ability to draw fine detail in the picture far surpasses conventional monitors, adding interest to the game.


If your monitor should need repair in the future, the technician should be familiar with the Vectorbeam monitor, because it is so different from the conventional raster system.

Interconnecting Cables are of 2 types: The Main Wiring Harness, and the Ribbon Connectors.

The Main Wiring Harness carries power from the power supply to the CPU, audio board, and monitor. It connects to each unit through the Molex plugs. The Molex plugs are built so they can only plug in the right way. NEVER CONNECT OR DISCONNECT THE MOLEX POWER PLUGS UNLESS THE GAME IS UNPLUGGED.

The Ribbon Connectors carry data to and from the CPU. Since they can plug in two different ways, care should be taken to plug them in correctly. For the CPU, the ribbons are plugged in correctly if the ribbon is naturally directed away from the board. (See Universal Bench Test Configuration, Section 7.) The ribbon at the monitor should also be directed away from the board. (See Universal Bench Test Configuration, pg. 7-3.) The audio board is different: the ribbon should go up across the audio board. (See Universal Bench Test Configuration, Section 7.)

# SOLAR QUEST OPTION SWITCHES LOCATED ON LOGIC BOARD AT POSITION E-2



#### TABLE ONE

SWITCH SWITCH

SHIPS

PER

4	5	GAME	
OFF	0 <b>F</b> F	2	
OFF	ON	3	
ON	OFF	4	
ON	ON	5	

#### TABLE TWO

**SWITCH** 

3

SWITCH

2

CREDITS

PER

COIN

OFF	OFF	1/1
OFF	ON	1/2
ON	OFF	3/2
ON	ON	3/4

#### DIAGNOSTIC MODE

- 1. Place switch 7 in the "off" position. This will put you into the Diagnostic Mode.
- 2. One of 3 tests will appear on the screen:

Alignment Pattern Intensity Test Game Status

To go to the next test, press the fire button on the Control Panel.

#### Alignment Pattern:

The correct pattern should be a LMD that fills the entire area of the screen.

#### Intensity Test:

The correct pattern should be a series of vertical lines going from max intensity on one end through minimum intensity at the other end. There are 256 lines on the display with 4 lines per intensity level with 64 levels totals.

#### Game Status:

The correct display is as follows:


Line #1 - #ships per credit

Line #2 - coinage option selects

Line #3 - daily credits

Line #4 - revision level

# DIFFICULTY LEVEL SETTING



(CIRCUIT BOARD LOCATED BENEATH PLAYER DIFFICULTY LEVEL SETTING CONTROL PANEL)

#### **SECTION 4**

#### OPERATOR'S GUIDE TO TROUBLESHOOTING

O.K. - this is where we get technical on you - but don't panic! We'll keep this as simple as possible so you can figure out which board to send out for repair. For some of the steps in this section you will need a simple VOM, and know how to use it.

Here are two important procedures we will refer back to in this section:

#### Checking the LED:

Whenever there is a problem with the game, a good place to check first is the LED (light-emitting diode) on the CPU board near the Molex power plug. This LED indicates whether most of the CPU circuit is working. When everything works right, here's what happens: Power to the game is turned on, the LED flashes on, then stays off. If the LED is flickering or on continuously, there is a problem with the CPU or the  $\pm 5$  volt supply. Check  $\pm 5$  volts on the logic board (follow procedures in this section). If the  $\pm 5$  is O.K., have CPU repaired.

#### Checking the +5 Volt Supply:

To check the +5 volts, you need a voltmeter. Turn power on in the game. Notice on the upper corner of the logic board nearest you is a little pin marked gnd. This is a great place to put the negative probe of the voltmeter. Near this pin in position T13 (see CPU layout, in appendix) is a 20 pin IC marked 74LS377. Ignore the other numbers on this chip. We can measure the +5 volt supply at pin 20. Pin 20 is the bottom pin on the far side of the chip. Put your positive probe there, without touching any other pins, and you should get a reading. Anything between +4.8 volts and +5.1 volts is o.k., otherwise, adjust the voltage.

The adjustment is located on the power supply and it is the only screwdriver adjustment on the power supply. Adjust slowly WHILE READING THE VOLTAGE. Too much voltage will destroy IC's fast. If voltage cannot be adjusted into the correct range (+4.8 - +5.1 volts), repair power supply.

#### **SYMPTOM**

#### WHAT TO DO

#### Circuit breakers trip

 Unplug game. Unplug Molex power plug from monitor and reset breakers. Turn POWER ON.

If breakers trip: POWER OFF, see 2.

- If breakers don't trip: Coin-up game and "play" it. Are all sound effects normal? Yes repair monitor.

  No Problem is probably in CPU or power supply. Check LED on CPU. Check +5 volts on CPU (see procedure) If +5 volts is good, repair CPU.
- Unplug Molex power connector from audio board, reset breakers and turn POWER ON.
   If breakers trip: Problem is in coin meter circuit or call factory for help.

If breakers don't trip: Repair audio board. POWER OFF, reconnect molex plug to monitor.

Turn power on to see if there is a good picture. If the picture is bad, problem is probably in the monitor. If breakers trip: Check LED and +5 volt supply. If LED and +5 volts is O.K., problem is probably in monitor.

## PART TWO

Information for Technicians

#### **SECTION 5**

#### **VECTOR THEORY**

In order to understand the basic concept behind a vector generated display, it is important to have a basic knowledge of vector theory.

In the vector display system, there are no horizontal and vertical lines (no sweep) or sync. A line generated using a vector system is shown in Figure 5-1.

A line is drawn by programming a beginning and ending point of the line to be drawn, and forcing the cathode beam to travel between these two points, illuminating the entire path on the screen of the CRT. The angle of the line, the position of the line, and the length of the line are determined simultaneously, and simply, by selecting the proper voltage levels for the beginning and ending points of the line.

This is accomplished by the two twelve-bit codes (words) applied to the DAC-80s on the display board. The DAC-80 will produce a

different voltage level at its output for each possible combination of input bits (of which there are 4096 possibilities for a 12 bit word.)

It is also important to remember the function of the LF 13331 analog switch and its output RC network. Because we are dealing with reactive components in C101 and C201 on the display board the charging voltages found are non-linear by nature. (See figure 5-2).

Therefore, when a line appears on the CRT, it is actually only part of the entire path taken between the beginning and ending points of the vector (C-D). The section of A-B is chosen as the most linear portion of the charge curve, and is illuminated.

Sections C-A and B-D are blanked at the cathode and section A-B illuminated by controlling IC7 (7406) on the display board. These calculations are all performed on the CPU logic board.




Figure 5-1. Line using Vector System




Figure 5-2. Non-linear Charging Voltages

When a line appears on the CRT, it is actually only part (section A-B), of the entire path taken between the beginning and ending points of the vector (section C-D). Section A-B is chosen as the most linear portion of the charge curve, and illuminated.

#### **SECTION 6**

#### THEORY OF OPERATION

#### GENERAL DESCRIPTION

This section describes the principles of operation of the major circuit functions of the Cinematronics Video Game. The system's general functional description is followed by detailed circuit schematics which are included as Appendix A. The schematics used in this manual are similar in nature to those used by most industrial electronic firms.

#### A. MONITOR

The <u>Vectorbeam tm\* Monitor</u> is unlike the conventional TV monitor in that it displays vectors (lines) generated from X-Y coordinates received from the logic board. The horizontal points are X (width) and the vertical points are Y (height). The X and Y logic signals originate from the logic board.

The Vectorbeam tm\* Monitor circuitry is so different from a raster scan monitor, it is useless to try to troubleshoot it using raster T.V. theory. The Vectorbeam tm\* Monitor has no horizontal oscillator, no vertical oscillator, no AFC, no sync circuits, and no video amplifiers. How, then, does it work?

The Vectorbeam tm\* Monitor can be divided into 4 main sections: voltage regulators; deflection circuits; video high voltage module; and brightness circuit (cathode drive).

There are three voltage regulators on the monitor board: +15v, -15v, +5v. Note that these are IC's, not transistors. The plus and minus 15 volt regulators supply both DAC-80's, the LF13331 analog switch, and the TL081 op amps. The +5 volt regulator supplies both DAC-80's and the 7406 (IC7). It takes little time and is well worthwhile to check all 3 regulator outputs every time the monitor is serviced.

Drawing a line requires two separate steps.

STEP 1. Digital information, in the form of a 12 bit word is applied to the input (pins 1 thru 12) of the DAC-80. Pin 1 receives the most significant bit, and pin 12 the least significant. The DAC-80 converts the digital word into an analog voltage which is outputted on pin 15. This voltage can swing between +5 volts, depending on the input word. The output of pin 15 then goes through a current limiting resistor R130 to the inputs of the analog switch IC1. (Pin 18 of the DAC-80 is an input for feedback). Now the CPU sends out an Initial Position pulse, closing the appropriate "switch" (actually a J-FET), to let the analog voltage out pin 10. C101 charges up immediately, and the analog voltage is amplified by IC 102 and the transistorized section Q101 thru Q111, causing the yoke to deflect the cathode beam to where we want the line to begin - the Initial Position.

STEP 2. Another 12 bit word is fed into the DAC-80. This word determines where the end of the line we are drawing will be. The DAC-80 again converts the digital word into an analog voltage that goes out pin 15 and into the analog switch IC1. Now the CPU sends out a Line Drawing pulse, closing the appropriate "switch" to let the analog voltage out pin 15 of IC1. The combination of R103, R102, and C101 has a time constant that determines how quickly C101 can charge (or discharge) to the new analog voltage on pin 15 of IC1. By adjusting R102, we change the amount of time it takes for C101 to arrive at the new analog voltage on pin 15 of IC1. Thus R102 determines the line length in the vertical (Y) direction. If the second (Line Drawing) analog voltage (IC1 pin 15) is greater than the first (Initial Position), the line will be drawn downward. If the second voltage is smaller, the line will be drawn upward.

In the horizontal channel, if the second analog voltage is greater than the first, the line will be drawn to the left.

Op-amp IC102 serves a dual purpose: It acts as a buffer between the deflection amplifiers and the analog switch, as well as an "edge gain" amplifier.

At the output of IC102, there is a resistor diode network consisting of R105 to R110, and D101 to D104. This resistor diode network is used to compensate for the non-linear characteristics of the CRT near the edges of the screen. If this circuit were not used, any object displayed on the screen would increase in size as it moved closer to the edges of the screen. Potentionmeter R109 adjusts the height of the pictures.

From the wiper of R109, the signal proceedes to Q101, which is the first stage of deflection amplification. Q101 to Q111 form a typical modern direct-coupled power amplifier with differential pair input and full complementary output. The differential pair consists of Q101 and Q103. The base of Q103 is tied to the amplifier output through the yoke and R117, forming a negative feedback loop. Q101 and Q103 (differential pair) compare input signal and amplifier output, and correct for any differences caused by amplifier distortion and the reactance of the yoke. Q102 is the constant current source for the differential pair (Q101, Q103). Bias for Q102 must be kept steady so Q102 collector current is constant. D105, D106 and R113 accomplish biasing. Note D105, D106 are in parallel with the base emitter junction of Q102 and R113. voltage across Q102 B-E junction plus voltage across R113 will equal total voltage across D105, D106, and the two forward biased diodes determine this voltage at 1.2 volts. Since the voltage across the B-E junction of Q102 is 0.6 volts, that leaves 0.6 volts across R113. The voltage across R113 is held constant, so the current through it is constant (I = E + R) at 3 Thus Q102 collector current is held ma. constant near 3 ma.

The output of the differential pair (Q101, Q103) is fed into the base of Q104. Q104 is a class A amplifier whose output feeds Q208 and Q209.

Q105 is another constant current source. D109, D110, D111 determine the bias current in Q108, Q109, Q110, Q111.

So the deflection signal has traveled to the base of Q108 and Q109, the driver transistors. If the signal happens to swing positive Q108 will turn on, turning on Q110 which drives current thru the yoke and deflects the electron beam down. If the signal swings negative, Q108 and Q110 turn off, Q109 and Q111 turn on, and the beam deflects upward.

If the signal amplitude is excessive Q110 or Q111 (also known as the output transistors) will conduct heavily. The excessive current will cause voltage to develop across R120 or R121, and Q106 or Q107 will turn on. When this happens, the signal is removed from the base of Q108, Q109. Q108 and Q110 or Q109 and Q111 are turned off by this action and are protected from burning up. So Q106 and Q107 are protection transistors, and during normal operation they are inactive.

Note that Q108, Q110 control deflection in the lower half of the CRT screen, while Q109, Q111 take care of the top half. In the horizontal (X) channel Q208, Q210 control the left half; Q209, Q211 control the right.

Because the amplifier is a direct coupled loop, it defies ordinary signal tracing as a means of troubleshooting. If the signal is wrong anywhere in the amplifier, it will be wrong throughout.

R122, R123, and C102 form a RC network, which compensates for any counter EMF that may develop by the expanding and collapsing of the deflection coil's electromagnetic field.

The video high voltage module operates off the +25v supply and generates three different voltages for three circuits. It generates 16KV for the CRT ultor voltage. It generates +400vdc for the CRT focus voltage. And it generates +90 volts for blanking the cathode. The +90v is well filtered and (ed into the brightness circuit on one end of R111

The brightness circuit controls the amount of current going from the CRT cathode to the phosphor screen. It does this by varying the voltage on the CRT cathode. It also incorporates protection circuitry to protect the phosphors from burns. The main components in the brightness circuit are IC7, Q1, Q2, Q3, Q6, Q7, Q8, and R111, the brightness control. There are only two levels of brightness used in this system, which I will refer to as Normal and HI. The brightness information comes from the 74LS32 in position J2 on the logic board, through the ribbon connector, and into IC7. Normal intensity data enters IC7-1, and HI intensity data enters IC7-3.

Normal intensity data then goes out IC7-2 and turns Q1 on-off. Q1 acts as an on-off switch connecting and disconnecting R7 to ground (thru Q2). Thus, when Q1 turns on, the CRT cathode voltage is lowered (assuming R111 is at a normal setting) and the beam is turned on. When Q1 turns off, CRT cathode voltage returns to +90 volts, and the beam is cut - off (no brightness on screen).

Hi intensity data goes out IC7-4 and turns Q3 on-off. Q3 collector is connected to R8 (10K) in parallel with R9 (2.2K), R10 (5.6K). When Q3 turns on there is a lower resistance path between CRT cathode and ground than there was when Q1 turned on. Thus CRT cathode voltage drops to a lower voltage, and more current flows to the phosphor screen, creating a higher brightness.

Note that when either Q1 or Q3 conducts, the only path to ground is through Q2. If Q2 is off, the CRT cathode voltage cannot change, and no picture can appear. This means Q2 is a master ON-OFF switch for the cathode beam, and is the means through which our protection circuits can turn the beam OFF.

The first protection circuit consists simply of an unfiltered full-wave rectified +25 volts from the power supply. This voltage is slightly filtered by C10 and fed through R6 to Q2, turning it on. When the game is unplugged, the +25 unfiltered dies immediately and the beam is cut off, preventing a bright spot on the screen.

The second protection circuit consists of Q6, Q7, and two sections of IC7. Part of this circuit turns off the beam if the -25 volts from the power supply is lost (breaker trips, or?). In the absence of -25 volts, IC7-9 goes high (pulled up via R20), and IC7-8 goes low, pulling the base of Q2 to ground and Q2 turns off.

The other part of the circuit protects against having the beam on too long (in case of CPU failure, etc.). The high going pulses coming out of IC7-2,4 that turn on Q1, Q3 also turn on Q6 via R22, R23. Q6 amplifies and inverts these pulses to high-going low. Pulses then go through another inverter, so at IC7-10 they are low going high (active high). The active highs here correspond to the times when the beam is on, and charge up C24. If the beam is on too long, C24 will charge up enough to turn on Q7, making Q7 collector and Q2 base go low and Q2 turns off. In normal operation C24 can discharge through IC7-10 when IC7-10 goes low.

Now, a paragraph about Q8. Q8 is the path through which IC7-2,4 receives its operating +5 volts. R19 and C23 form a time delay, so when power is first turned on it takes a while before Q8 turns on and +5 volts gets to IC7-2,4. Thus, all other circuits get a chance to stabilize before the beam is turned on.

R111 is the brightness potentiometer, which adjusts the amplitude of the negative pulses used for Normal and HI brightness.

#### B. MULTI-INTENSITY CIRCUIT BOARD

The MULTI-INTENSITY CIRCUIT BOARD which is located on the rear of the display chassis, allows lines to be drawn at any one of 64 different intensity levels.

#### CIRCUIT DESCRIPTION

MULTI-INTENSITY CIRCUIT BOARD is composed of 4 main circuits, they are: an INPUT LATCH, CLOCK CONDITIONING CIRCUIT, DIGITAL to ANALOG CONVETER (DAC) and BEAM ON/OFF SWITCH.

#### INPUT LATCH

The INPUT LATCH is an 8 bit latch U1, of which 6 bits are used. The inputs to U1 are fed from bits 45 thru 55 of the X-DAC. The clock input of the latch is tied to the output of the clock conditioning circuit U4-2.

#### CLOCK CONDITIONING CIRCUIT

The clock conditioning circuit is composed of 3 Schmidt-Trigger inverters, U4, one section of an open collector inverter U3, R9 and C1.

After valid data is present on the data inputs of U1, a high going strobe pulse is sent to U4-3 via J1-14. This strobe pulse is filtered by R9 and C1 such that strobe pulse "glitches," under 100 nsec, are ignored and valid strobe pulses of 600 nsec are fed to U1-11.

#### DIGITAL to ANALOG CONVETER (DAC)

The DAC is composed of U2, U5 pins 1-6, D1-D18, R1-R6, and Q1-Q6. Q1 handles the most significant bit and Q6, the least significant bit. Six similar current sink circuits are used to vary the amount of current drawn thru the 10k briteness pot on the display board. The amount of current drawn by each current sink is determined by the values of R1-R6. Note that R1-R6 are related by powers of 2. Note also that as more current is drawn through the 10k briteness pot the voltage on the pot wiper will decrease causing the beam on the CRT to become brighter.

A current sink will be turned on if it's respective driver, for instance U2-10, is high when Q7 turns on, grounding it's collector. In all other cases it will be off.

D1-D6 act as voltage limiters to protect the outputs of U2. D7-D12 protect the current switching transistors Q1-Q6 by limiting the reverse bias voltage across the emitter base junctions of Q1-Q6 to 0.7 volts.

D13-D18 block reverse currents. Without these diodes the collector of Q7 would never be able to reach  $\pm 90$  volts even with Q7 turned off.

R7 and the contrast pot R11 act to reduce the contrast provided by the DAC by shunting it's current output.

#### BEAM ON/OFF SWITCH

The BEAM ON/OFF SWITCH consists of a Schmidt-Trigger inverter, U4 pins 5 and 6, R10, C2, and Q7. After an intensity level has been selected by strobing data into U1 the beam is enabled by the CPU with a low level on U4-5. This will cause Q7 to turn on, grounding its collector (less than 1 Volt). The spot kill line is connected to Q2 on the display board. It is normally near ground, about 0.3 volts.

The spot kill line will become an open circuit only if the CPU attempts to hold the beam on continuously or if there is a loss of the +5, +25, or -25 Volt power supplied at the supply board. R8 acts to "pull up" the collector of Q7 when it is turned off.

#### TROUBLESHOOTING

The troubleshooting procedure for the multiintensity board is a rather straightforward operation.

First, power down the game. Disconnect P1, the 34 pin ribbon cable connector; this disconnects the multi-intensity board from the CPU board. Also, the round connector plug at the neck of the CRT MUST be disconnected to prevent burn marks on the screen.

After these are both unplugged, power up the game and proceed to pin 14 of J1. Since the clock circuit consists primarily of inverters, testing is very basic. With J1-14 open check for "highs" on U3-4 and U4-2. Also verify that U4-4 and U4-12 are low. Using a test lead, ground J1-14. Recheck the last four measurements. Verify that all highs and lows are reversed.

Note that R9 and C1 form a filter which is invisible at low frequencies, as in this test.

The next step is to test the input latch and inverter, known as U1 & U2 respectively. With J1-30, open U1-14 should be "high." Tap the clock input, J1-14, with a grounded test lead. This will clock the high through to U1-15. U2 is an inverter so U2-10 should be low. This procedure is the same for pins 29-25 of J1. Next, hook a grounded jumper to J1-30. Tap the clock input, J1-14, with another grounded test lead, this should cause U1-15 to go low and U2-10 to go

high. Next, proceed with the beam on/off switch. With J1-12 open check for a low on U4-6. Also verify that the collector of Q7 is near +90 volts. Using a test lead, ground J1-12. U4-6 should be high and the collector of Q7 should be near ground, about 1 volt.

To troubleshoot the DAV turn the contrast pot fully clockwise (maximum resistance). Using a test lead, ground J1-12. Check for 45 volts at J2-1.

Now using a test lead, ground J1-30. Tap the clock input, J1-14, with another grounded test lead. Recheck J2-1 for a voltage reading near 29.1 volts. Repeat this procedure for J1 pins 29 thru 25. Refer to table 1 for voltage readings at J2-1.

The contrast pot will change the voltages measured at J2-1 if not kept at the same position during the test.

TABLE #1

J1 (pins 25-30) input from CPU (grounded)	J2 Pin 1 Voltage	Voltage difference between "steps"
30	29.1	C 1
29	35.2	6.1
28	38.5	3.3
27	40.0	1.5
26	40.8	.8
_~		.3
25	41.1	

#### **NOTES**

- 1. The voltages listed in the table may vary somewhat. The voltage difference between steps are related roughly by powers of two.
- 2. Contrast pot was full CW.
- 3. Q7 "off" and pins 25-30 open = 93.8 volts at J2-1.
- 4. Q7 "on" and pins 25-30 open = 41.6 at J2-1.

#### **INTERFACE SIGNALS**

There are 2 plugs for connecting the multiintensity board to a modified Vectorbeam monitor. The monitor modification will be briefly covered first.

Deleted from the monitor were the following items: Q1, Q3, R7, R9, and R22. Q1 and R7 were used to control high intensity. Q3 and R9 controlled the cathode drive for the normal intensity, respectively. R22 was removed from the spot kill protection circuit because the signal that drove the high intensity is now used to clock data into the latch on the multi-intensity card. The signal that drove the low intensity (J1-12) now drives the beam on circuit on the multi-intensity board.

The 9 pin Molex connector on the multiintensity board supplies all the voltages needed by the board as follows:

#### CONNECTOR TABLE

J2 (pin)	Function
1 2 3 4 5 6 7 8	to R11, brightness pot.  N/C  from Q2 "spot kill" on monitor.  +90 volts.  N/C  N/C  N/C  N/C  N/C  SN/C  SN/C
J1 (pin)	Function
1-11 12 13 14 15 16 17 18-24 25-30	N/C spot kill from CPU board N/C clock input from CPU board W1 presently grounded N/C W1 presently grounded N/C controls from X-coordinate drives of CPU board. 25-30 control 64 different levels of intensity.
31-34	N/C

The processor hardware can be broken down into five basic functional blocks as shown in Figure 6-1. The arrows indicate the possible data flow directions between the various blocks. The ALU and Control block are the main components of the processor while the

Memory and I/O blocks may be thought of as merely peripherals. Figure 6-2 is a detailed block diagram of the processor. The numbers in each block correspond to the entries in Table 6-1, which lists the IC numbers of the main components of each functional block.




Figure 6-1. CPU Functional Block Diagram

The following is a brief description of each block shown in Figure 6-1. The numbers beside each functional block name are the numbers in Figure 6-2 which correspond to a particular function.

#### **RAM** (6)

The RAM is implemented with three read/write static memories configured as a 256 x 12 bit block. Data can be transferred to or from this memory via the ALU block. The processor uses this RAM as a scratch pad.

#### ROM (10)

The ROM is configured as an 16K x 8 bit block of memory. These memory locations contain the program instructions and/or data. It is accessed via the processor control unit.

#### I/O 19, 17, 18

The I/O block consists of 8 output lines implemented with a bit addressable latch, 24 input lines implemented with data selectors, and two 12 bit registers which are connected to the X-Y display deflection circuits via D/A convertors.

#### Arithmetic Unit 1,2,3,4,5

The arithmetic unit performs all the arithmetic processing for the system. It consists primarily of two 12 bit accumulators, an arithmetic logic unit and various data selectors. The accumulators can function as temporary storage registers for arithmetic functions upon the data in the accumulators. The data selectors are used to select the various sources of data which will be processed.

#### Control Unit (15,16,14,7,8,9,11,12,13)

The control unit is the heart of the processor. It performs all instruction decoding operations and generates all the necessary control signals which the rest of the hardware requires to function correctly.

The following is a discussion of each block shown in Figure 6-2.

#### 1. Accumulator Selector

The accumulator selector consists of 3 quad data selectors. They are used to select the output of either the primary or secondary accumulator for processing by various other sections of the systems.

## 2 & 3 Primary and Secondary Accumulators

The two 12 bit accumulators are implemented with quad bidirectional shift registers. The primary accumulator consists of S4, P4, M4. The secondary accumulator consists of T4, R4, N4. All data manipulation in the processor is accomplished using these two accumulators. All output data flows through these registers.

#### 4. Arithmetic Logic Unit (ALU)

The ALU is used to perform all necessary arithmetic functions within the processor. The ALU is implemented using three 24LS181 (N6M6L6) function generators, three 74LS85 (N9,M9,L9) 4 bit magnitude comparators, and a 74S182 (L4) look ahead carry generator. The data which the ALU manipulates can come from four different sources. The first source is the contents of the accumulators via the accumulator selector. The second and third sources are the ROM and RAM data outputs via the ALU data selector (N11, M11, L11) and the fourth source is the external input selector (E4, D4, C4).

#### Data Selector

The data selector is used to read data into the ALU from either the RAM or ROM memory. Note that the ROM data is only 8 bits wide while the RAM data is 12 bits wide.

#### 6. RAM Storage

The system RAM consists of three 9101C high speed static memory chips connected as a 256 x 12 bit block. The block is 12 bits wide in order to allow the contents of an accumulator to be stored. The processor uses the RAM as temporary storage of program variables, data pointers or any other data of a dynamic nature.

#### 7 RAM Address Selector/Register

The output of this register is tied directly to the address lines of the RAM. It consists of a multiplexer which routes address data from either the ROM or RAM locations to the RAM address lines. The capability to use RAM data to select RAM addresses is the basis for the indirect addressing mode of the processor.

#### 8. Page Selector

The page selector is used to latch the high order 4 bits of a RAM access instructions.

#### ROM Data Register

The register is used to temporarily hold data from the ROM during an instruction fetch.

#### 10. ROM Memory

The ROM memory consists of the actual memory chips plus a data selector and latch circuit. The latch is used to improve the memory access time during a two byte instruction fetch by allowing one byte of the instruction to be latched while the RAM address lines are decoded for the other byte. The data selector can then be used to rapidly access both bytes of the instruction by switching between the latch and memory outputs.

#### 11. Instruction Register

The instruction register is a latch which holds the current op code as read from ROM. Its output is tied to the instruction decode circuitry which in turn generates the necessary signals to execute the instruction.

#### 12. System Sequencer

The system sequencer is used to decode an instruction op code and to generate the appropriate timed sequence of signals which execute the instruction. The op code is decoded by using it as the address data to a set of decoder ROMS. The outputs of the decoder ROMS are then synchronized with the system clock and used to control the various system functional blocks.

#### 13. Line Length Counter

The line length counter is used during the process of drawing a vector to control the length of a vector, by turning off the beam at a pre-determined time after the vector is intiated. The counter is loaded with a value from a line length ROM and then counts up until it overflows which in turn generates a signal to indicate the vector has been finished.

#### 14. Program Address Selector

This selector is used to provide the address data to the program ROM. It selects either the program address counter output or the accumulator selector output and routes this data to the ROM address lines. The ability to use the accumulator contents as address data allows the program to randomly access data tables stored in the ROM or to compute a branch address after a conditional test.

#### 15. Program Address Counter

This is a 12 bit counter whose output defines the next location in ROM to be accessed. It is normally clocked sequentially to step through a program. However, it can be loaded with data from the program address register which is how the jump instructions are implemented.

#### 16. Program Address-Register

This register is a latch used for temporary storage of an address which will be loaded into the program counter during a jump instruction. The input data to this latch can come from either the program ROM or the scratch-pad RAM.

#### 17. Input Selector

The input selector is used to read the state of one of the 24 input lines into the selected accumulator. There are 16 primary inputs and 8 secondary inputs. During an input instruction the upper 11 bits of the accumulator are set to zero while the least significant bit reflects the state of the input line. All input lines have pull up resistors on them so that they will read high if they are left unconnected.

#### 18. Output Selector


The output selector is a bit addressable latch used to control the 8 output lines. During an output instruction the selected output line is set to the complement of the least significant bit of the accumulator. The output lines are used to control the audio board, display intensity and the mechanical coin counter.

#### 19. Display Registers

The display registers are the interface between the processor and the display driver circuits. These registers are latches into which the contents of the accumulators can be stored. The outputs are tied to D/A converters which provide the input voltage to the display deflection amplifiers.

#### TABLE 6-1. BLOCK NUMBERS AND COMPONENT I.C.

- 1. T-2, R-2, N-2
- 2. S-4, P-4, M-4
- 3. T-4, R-4, N-4
- 4. N-6, M-6, L-6, N-9, M-9, L-9
- 5. N-11, M-11, L-11
- 6. N-14, M-14, L-14
- 7. J-12, I-12
- 8. H-12
- 9. S-13
- 10. U-7, R-7, T-7, P-7, U-9, T-9, U-11, T-11
- 11. T-13
- 12. A-8, G-10, F-10, G-14, F-14, E-14, D-14, C-14
- 13. E-6, D-6, E-8, H-8, G-8, F-8
- 14. S-9, R-9, P-9
- 15. S-11, R-11, P-11
- 16. P-13, R-13
- 17. E-4, D-4, C-4
- 18. F-2
- 19. S-2, R-2, M-2



6-10

#### D. AUDIO BOARD

#### CIRCUIT DESCRIPTION AND TROUBLESHOOTING GUIDE

#### GENERAL INFORMATION

The following section describes the theory of operation for the Solar Quest audio board. The last part of this section contains block diagrams of the audio board. The theory of operation of each block will be described along with test techniques to enable effective troubleshooting.

#### **DEFINITIONS**

TTL (Transistor - Transistor Logic) compatible levels are defined as follows:

- 1. A TTL "low" or logic O is any voltage less than 0.8 volts.
- 2. A TTL "high" or logic 1 is any voltage less greater + 2.4 volts.

VCO: Voltage Controlled Oscillator CCA: Current Controlled Amplifier U: Integrated Circuit (chip)

#### **NOTATION**

A particular pin of an IC (Integrated Circuit) is denoted in the text by first the chip designation and then the pin number: e.g. U25-10 means pin 10 of U25.

Jumper patches W1 thru W16 are sections of traces on the audio board designed to be severed in order to isolate a section of circuitry for test purposes. Be sure to sever between the two eyelets, one round and the other square. The orientation of these pads is the same on the board as on the schematic diagram. Repair by adding a short jumper wire into the holes provided.

DO NOT repair any trace by adding a blob of solder at the sever. This will cause intermittent operation.

## TEST PROCEDURE (refer to Sheet 1 of the Schematics)

To verify proper operation of U1 and U2 disconnect the 16-pin ribbon cable at J2 and decreas the volume. Check U1-4, 12, 8 and U2-6 with a logic probe, scope, or meter. They should read high or 2.4vdc - 5 vdc (Logic 1).

Next, with a test lead, ground U1-1. U1-4 should now measure low or 0 to 4 vdc. Follow this procedure for the other three pairs of Schmitt-Trigger circuits.

To verify proper operation of U3 and U4, Load all lows into their output ports by tying U1-1 to grounf. Using another test lead connected to ground tap U1-5 twenty times. Outputs QA-QH on both IC's should measure low.

Repeat the above procedure, but remove the grounded test lead from U1-1. This should load all highs into all the output ports.

To check U7, first, load U3 with all lows and tap pin 11 with the grounded test lead and measure the outputs 1G-8Q. They should all measure low. Next, load U3 with all highs and again tap U7 pin 11 with the grounded test lead. The outputs should be high.

To check U's 5 and 6 load U's 3 and 4 with all lows and tap a grounded test lead to U23-10. Measure the outputs 1G-8Q on each. They should all measure low. To load all highs into U5 & U6, load all highs into U3 & U4, and tap U23-10 with the grounded test lead. NOTE: if problems are encountered here the music gating circuit may be at fault. Refer to its troubleshooting procedure if necessary.

## TEST PROCEDURE (Refer to Sheet 2 of the Schematics)

With a logic probe verify U24-12 is switching high and low or measure a 20MHz square-wave with a scope. U25-5&6 should measure 10MHz square-wave and U25-8&9 should measure 5MHz square-wave.

To verfiy proper operation of the Divide-by-Eleven circuit, tie one end of a test lead to ground and connect the other end to TP1. U15-6 should be high. Pins 11, 12, 13, 14 and 15 of U26 should all be toggling. Move the ground from TP1 to pin 9 of U26. Pins 11 & 13 should be low, pins 12 & 14 should be high. Remove the ground lead from Pin 9. Check the outputs of U27. Pins 2 & 3 should be toggling and measure 227KHz.

## DIGITAL NOISE GENERATOR (Refer to Block Diagram 2)

The digital noise generator is comprised of three cascaded serial in-parallel out shift registers. Four outputs from the third shift register are mixed together via 3 exclusive-or gates. The resulting signal is then used two places: One is to feed an anti lock-up control circuit and the other is to provide the input data for the first shift register. The output, taken from the QH output of the final shift register, is then fed into an amplifier to convert the signal from TTL level to a 12v P-P analog signal.

#### Shift Registers

U's 28-30 are 8-bit parallel output shift registers. Random data is generated by the combination of a long shift register in conjunction with a binary addition function. Consequently, three shift registers are used in a cascaded format. The clock signal for the three shift registers comes from the two phase clock generator displayed on block diagram three.

#### Mixer

The mixer is made up of 3 exclusive - OR gates whose inputs are taken from the final stage shift register.

The three gates perform a logical addition of 4 selected taps of the 24 stage shift register. U18-11 is then fed back to the input of the first stage shift register via an inverter (U24).

#### Anti Lock-Up Control

If at any time all outputs of the shift registeres becomes "ones," the input to the 1st stage will become a "one" and the shift registers will lock-up in an all "ones" state.

U31 is a binary counter wired up to provide the shift registers with a reset pulse if it counts 32 successive "ones." However, under normal conditions, U31-10 will never go high because the longest successive string of "ones" will normally span 23 clock pulses.

## Trouble Shooting (Refer to Sheet 2 of the Schematics)

With a test lead, ground Pin 11 of U18. Using a logic probe or scope monitor the outputs of all three shift registers. They should all be toggling. Pins 12 & 13 of U18 should also be toggling. U31 will now act as a straight binary counter so its outputs should also be toggling.

#### NUKE (Refer to Block Diagram 6)

The nuke sound is heard whenever a player strikes the nuke button and will continue to be heard until either the nuke button is struck again or the nuke hits an enemy ship.

A gated oscillator (U13) feeds a two phase clock generator (U14). Two of the four clock signals generated are used to clock a divide-by-191 circuit. One of these clock signals is also used by a divide-by-128 circuit (U17). A third clock signal is used by the load control circuitry. The divide-by-191 circuit is further divided by two at U16 and mixed together with the output of the divide-by-128 by U18.

#### Gated Oscillator

U13 is a 555 timer IC which outputs a square wave whenever Pin 4 is high. R4, R5, and C1 determine the frequency of oscillation.

To verify proper operation of U3 and U4, load all lows into their output ports by tying U1-1 to ground. Using another test lead connected to ground tap U1-5 twenty times. Outputs QA-QH on both IC's should measure low.

Repeat the above procedure, but remove the grounded test lead from U1-1. This should load all highs into all the output ports.

To check U7, first, load U3 with all lows and tap pin 11 with the grounded test lead and measure the outputs 1G-8Q. They should all measure low. Next, load U3 with all highs and again tap U7 pin 11 with the grounded test lead. The outputs should be high.

To check U's 5 and 6 load U's 3 and 4 with all lows and tap a grounded test lead to U23-10. Measure the outputs 1G-8Q on each. They should all measure low. To load all highs into U5 & U6, load all highs into U3 & U4, and tap U23-10 with the grounded test lead. NOTE: if problems are encountered here, the music gating circuit may be at fault. Refer to its troubleshooting procedure if necessary.

#### QUICK CHECK PROCEDURE

At this point, all of the sounds generated on the audio board can be checked. Follow the above procedure for loading all "ones" into the control latch U7. The Nuke sound should be turned on at this time. To turn it off, ground U7 pin 15 with a test lead. With another test lead, tap the following pin numbers on U7 to activate the corresponding sounds.

#### SOUND CHECK TABLE

Pin number on U7	Sound
2	Loud explosion
5	Soft explosion
6	Thrust
9	Capture
12	Fire
16	Photon

To check the Music circuit, load all "ones" into the output latches, U5, U6 & U7 as described above. Ground U7-15 with a test load to disable the Nuke sound. With another test lead, ground either pin 5, 6 or 9 of U5 to enable the music amplitude signal. With yet another grounded test

lead, tap pins 12, 15, 16, & 19 on U5 and pins 2, 5, 6, & 9 on U6. A different tone should be heard for each grounded pin.

## MASTER CLOCK CIRCUITRY (Refer to Block Diagram Two)

The crystal and 3 inverters (1/2 U24) constitute a 20MHz oscillator. U25 is a J-K flip-flop used to divide the 20MHz down to 5MHz. U26 and U15 together constitute a divided by eleven circuit. This is accomplished as follows: U26 is a presettable binary counter. By preloading the input with five (pins 3 & 5 pulled high and 4 & 6 grounded), the counter starts counting from 5 to 15 every time a clock pulse arrives at pin 2. At fifteen a carry pulse is generated at Pin 15 and is fed to Pin 2 of a D-flip-flop (U15). The output of U15 then goes low for one clock pulse. The low is fed to the load input of the counter and it starts counting from 5 to 15 all over again. Thus, the frequency at the output of U15 is 5MHz/11. This signal is then fed to a J-K flip-flop which toggles every time a clock pulse occurs at Pin 12, making the output 1/2 its clock input of 227KHz.

#### Two Phase Clock

The two phase clock utilizes both halves of a 74LS74 (U14) and two inverters (U2). This circuit generates 2 square waves 90 degrees out of phase and their compliments. This phasing insures that U11-2, U12-2 and U15-11 are clocked in sequence.

#### Divide-By-191 and Load Control Circuit

U11 & U12 comprise an 8-bit binary counter. When the "N-Load-" signal appearing at Pin 9 of both U11 & 12 goes low and each gets clocked, the binary equivalent of 65 gets preloaded into the 8-bit binary counter. After 191 clock cycles, the carry output of U11 (Pin 15) goes high. During the same clock cycle, this signal, also appearing at U15-12, gets clocked through causing U15-8 (N Load-) to go low. Consequently the binary counter is again preloaded with 65 and the cycle repeats itself.

#### Divide-By-Two Circuit

This circuit simply consists of a J-K flip-flop (U16) which is wired such that the output toggles every clock pulse.

#### Divide-By-128

This circuit is simply two cascaded 4-bit binary counters (U17). Pin 9 is a square wave which toggles every 64 clock pulses appearing at Pin 1.

#### Mixer

The mixer consists of one exclusive -OR Gate (U18) that logically adds the results of the divide-by-128 circuit and divide-by-2 circuit.

## Trouble Shooting (Refer to Sheet 1 of Schematics)

Load all "ones" in the output latch, U7 as described in the input control circuitry. Monitor the signal at U13-3. It should be a square wave with a period of about 23usec. Check the signals appearing at Pins 5, 6, 8, 9 of U14. They should all be square wave with a period about 46usec. To insure proper operation of U's 11 & 12, ground TP4 with a test lead. U15-8 should remain high so U11 & 12 will act as standard binary counters. With a logic probe or scope, check pins 11-15 on each IC. All should be toggling. Remove the ground from TP4 and move it to U15-8. Again check the outputs of U11 & 12. Pins 11, 12, 13, 15 of U12 and 11, 13, 14, 15 of U11 will be low. Pins U12-14 and U11-12 will be high. Remove the ground from U15-8. Check pins 3-6 & 8-11 of U17. All should be toggling.

## LOUD EXPLOSION (Refer to Block Diagram 4)

The loud explosion is activated whenever a player's ship is blown-up. The basic components of this circuit are white noise, from the digital noise generator, a low pass filter, a current controlled amplifier (CCA), an envelope control circuit and a voltage switch.

#### Low Pass Filter

The output of the noise generator circuit is fed into the low pass filter, R15-19, C16 and C7. The filtered output is then fed directly into the CCA (U33).

## Current Controlled Amplifier (CCA) (Refer to Figure 1)

U33 can be imagined as an amplifier that generates a current wave form at Pin 6 characteristic of the voltage appearing at Pin 2. The gain of the output is proportional to the amount of current injected into Pin 5.

#### **Envelope Control**

R26 limits the amount of current injected into Pin 5 of the CCA and the RC time constant of R26 & C8 determines the envelope or decay time of the output waveform at Pin 6.

#### Voltage Switch

This circuit is turned on by placing a low level at the junction of R20 & R21. Q1 gets forward biased and turns on. This subsequently forward biases Q2 and injects current into the CCA.

## Test Procedure (Refer to Sheet 3 of Schernatics)

With J2 disconnected from the CPU board, load all "ones" into the output latch (U7) as described in the input control circuitry section. Next ground Pin 15 of U7 to turn off the nuke sound. The junction of R20 & R21 should measure about +5vdc. Grounding this point should cause the collector of Q1 to switch from -3.5vdc to about +5vdc. This results in forward biasing Q3 and causing its collector to change from about -14.5vdc to about +5vdc. If for any reason the voltage switch circuit is suspect, it may be eliminated by cutting W3. By tapping a grounded test lead to the square pad of W3, current is injected into the CCA and an explosion should be heard. If not, verify that the noise generator is functioning properly and R15 is receiving the noise signal. If any of the following sounds work (see Quick Check Procedure), thrust, music or photon replace U33. If none of the above work, perform a check of the voltage follower circuit (see voltage follower). If the voltage follower is operating correctly, one of the other CA3080's may be shorted. To isolate any one of them whose outputs feed the voltage follower, cut the appropriate test jumper until the explosion circuit works.

#### Voltage Follower (Refer to Block Diagram 7)

R147 converts the total current output of all the CA3080's to a voltage. Since this is a high impedance point, U49 is used to amplify the signal at Pin 3 before feeding it to the pot driver (U50)

## Test Procedure (Refer to Sheet 3 of Schematics)

If any of the following sounds work, music, loud and soft explosions, thrust, photon, it's pretty safe to assume that U49 is working properly. However, if none of these sounds work, cut W16 and apply a known good signal via a test lead to the square pad of W16. The output of the noise generator, Pin 6 of U32, is a good choice. If the input control latch is set up properly so that no other sounds are on, the noise signal should be heard on the speaker.

## SOFT EXPLOSION (Refer to Block Diagram 4)

The soft explosion is heard whenever an enemy ship or survivor is destroyed. The technical description is identical to that of the loud explosion. The difference between the two circuits only being the component values in the envelope control circuitry giving the sound a faster decay time and lower volume.

## Test Procedure (Refer to Sheet 3 of Schematics)

See Test Procedure for Loud Explosion.

## THRUST (Refer to Block Diagram 4)

The thrust sound is activated whenever the player's ship is in motion. The technical description is identical to that of the loud explosion sound. The differences between the two circuits are different component values in the low pass filter and envelope control circuitry. These are responsible for a different frequency response, amplitude, attack and decay times.

## Test Procedure (Refer to Sheet 3 of Schematics)

See Test Procedure for Loud Explosion sound.

#### CAPTURE (Refer to Block Diagram 5)

The capture sound is heard whenever a player's ship retrieves a survivor. The circuitry to create this sound consists of a low leakage swtich, voltage controlled oscillator (VCO), TTL level converter, and a binary counter.

A low level applied to the input of the low leakage switch causes a change in voltage at Pin 5 of the VCO (U42). This control voltage causes the frequency at the output of the VCO to sweep up. As the signal rides on a DC level, a coupling capacitor is used to A-C couple the signal to a bipolar-to-TTL level converter consisting of R92-94, Q13, D7 and D8. This signal is then fed into a binary counter (U21) where it is divided by two. The signal is then adjusted for volume by R95-97 and A-C coupled by C22 before being sent to the summing junction.

23

## Test Procedure (Refer to Sheet 3 of Schematics)

Load all "ones" into the output latch U7, as described in the Input Control Circuitry section. With a test lead, ground U7-15 to disable the nuke sound.

Measure the collector of Q11. With another grounded test lead, tap the junction of R82 & R83, it should switch from -3.5vdc to about +5vdc. Next measure the collector of Q12. It should switch from +14vdc to GND. Pin 5 of U42 should switch from about +14vdc to about +12.5vdc.

If there is any doubt concerning the operation of Q12, cut W10. A grounded test lead may be used to simulate the action of Q12 by touching the test lead to the square end of W10.

Next, measure the frequency at Pin 3 of U42 with R82-83 ungrounded. It should have a period of about 0.86ms and be riding on a +6vdc level. It should be approximately 8V P-P in amplitude. Next ground the junction of R82 & 83. The period should be about 0.2ms. Remove the ground from the junction of R82 & 83.

Next check the collector of Q13. The period should be identical to the signal at U42-3, and have TTL compatible levels.

To insure proper operation of the binary counter (U21) monitor Pin 1. Again the signal here should be identical to that of the collector of Q13. Pin 2 should be high as well as Pins 3 through 6. Next ground the junction of R82 & 83. Pin 2 should now also be grounded and the outputs Pins 3-6 should be toggling.

## PHOTON (Refer to Block Diagram 5)

The photon sound is heard whenever a nuke is fired from a player's ship. Featured in this circuitry is a free-running oscillator (U35) which feeds a low-leakage switch. The switching voltage level at the output of the low-leakage switch feeds a discrete wide-range voltage-controlled oscillator (WR VCO), U's 36-40, whose output is injected into a current controlled amplifier (CCA), U41. A voltage switch and amplitude control circuit then determine the characteristics of the CCA output wave form.

## Free Running Oscillator (Refer to Sheet 3 of the Schematics)

U35 is a 555 timer IC configured to operate as a free-running oscillator. R47 & 48 and C13 determine its operating frequency.

#### Low Leakage Switch

The low-leakage switch consists of the following components: R49-54, Q7 and Q8. A low level of the junction of R49 and R50, forward biases Q7 turning it on. The collector voltage switches from -3.5vdc to about 5vdc. Subsequently Q8 gets forward biased and its collector voltage switches from +14vdc to about ground.

R59 & R60 form a simple voltage divider. The resulting voltage is fed to Pin 3 of U36. When Q8 gets turned on, R58 is placed in parallel with R60, thus changing the voltage divider and the voltage at U36-3. C15 is used to determine that rate of change.

# Wide Range Voltage Controlled Oscillator (WRVCO) (Refer to Block Diagram 8 and ' Sheet 3 of Schematics)

The WRVCO consists of U's 36-40. U36 is a voltage follower whose output is directly proporational to the changing voltage appearing at Pin 3. U37 is configured and an inverting amplifier whose output is equal but opposite to that of the voltage follower. These two outputs determine the upper and lower limits of the VCO. U's 38 & 39 are used to compare the capacitor voltage appearing at C16 to the upper and lower limits set by U36 & 37. The comparator outputs are summed together via R65 & 69 and fed to an Analog Flip-Flop (AFF), U40.

D5 and D6 limit the output of the AFF to +/-10.7vdc, which is then fed to an integrator R71 & 69 and fed back to the two comparators.

Assume the upper limit equals +5 vdc. The lower limit would then be -5 vdc. Further assume the output of the AFF is sitting at -10.7 vdc and the capacitor voltage is slightly negative. The capacitor voltages starts charging toward -10.7 vdc. When it goes slightly more negative than -5 vdc, the lower comparators are positive, forcing the AFF to switch from -10.7 vdc to +10.7 vdc, and the capacitor voltage begins charging toward +10.7 vdc. The cycle then repeats itself.

If the upper and lower limits are increased in magnitude, it will take more time for the capacitor to charge and discharge, causing the output frequency to decrease.

#### CCA (Current Controlled Amplifier)

The output of the WRVCO is fed to a current controlled amplifier, U41. For a technical description, refer to Loud Explosion Section.

#### **Envelope Control**

C17 & R81 determine the signal level and envelope decay of the output waveform at U41-6. For a technical description refer to Loud Explosion Section.

### Voltage Switch

R75 through R80, Q9 and Q10 comprise the voltage switch used to enable the photon sound. The technical description is identical to that found in the Loud Explosion Section.

### Test Procedure (Refer to Sheet 3 of Schematics)

Load all "ones" into the output latch (U7) and ground U7-15 to disable the nuke sound. Check the output of the free-running oscillator, U35-3. A TTL level square wave with a period of 140ms should be present. The collector of Q7 should be a square-wave switching between -3.5vdc and +5vdc with a 140ms period. The collector of Q8 should be switching between +11vdc and ground, with a 140ms period. However, instead of a square-wave, the signal should be an RC charging waveform.

The waveform at U36-6 should swing from +2vdc to +11vdc and resemble that at the collector of Q8. The waveform at U37-6 should swing from -2vdc to -11vdc and be exactly opposite that of U36-6.

To check the operation of U38-40 tie the junction of R71 & C16 to +15vdc with a test lead. Pin 6 of each IC should measure -15vdc. Next tie the junction of R71 & C16 to -15vdc supply. Pin 6 of each IC should now measure +15vdc. Remove the test lead.

To insure proper operation of the voltage switch, ground the junction of R75 & 76. The collector of Q9 should measure about +5vdc. The collector of Q10 should also measure +5vdc.

If any of the following sounds work change U41: Loud Explosion. Soft Explosion. Thrust or Music. If none of the above work, refer to the section labeled voltage follower.

### FIRE (Refer to Block Diagram 6)

The fire sound is heard whenever a player depresses the fire button. Noise is injected into a discrete voltage control bandpass filter made up of U's 43-37 and components R98-107, R109-112, R120, and C23-25.

R108 & R119 and C26 comprise the amplitude, envelope and frequency control. A voltage switch (Q14, Q15 and R113 through 118) provides the means of enabling the sound.

### Voltage Controlled Bandpass Filter (Refer to Block Diagram 9)

U44 and U46 are current controlled amplifiers (CCA). They are involved in performing two key functions in this circuit. First, U44, R108, C26, U45, R119 and C26 control the amplitude of decay of the signal appearing at the bandpass output. For a description of this function refer to the CCA and Envelope Control subtitles under the Loud Explosion Section.

Secondly, with the addition of C23 and C25, the CCA's provide frequency control. This is accomplished as follows: The CCA's are current sources. A current source and a capacitor constant and varying the strength of the current source will give the effect of varying the capacitance. When the CCA's are turned on hard by applying a low to the input of the voltage switch (refer to description of voltage switch under Loud Explosion Section) the current sources provide their maximum current. When the low is removed from the voltage switch and C26 starts discharging the CCA's provide less and less current drive. The effect is the same as if the capacitance of C23 & 25 were slowly increasing. Consequently, the frequency response of the circuit starts to decrease and we have in effect variable frequency active filters. U45 & U47 are high impedance buffers used to minimize circuit interaction between the two CCA's.

U43 serves as a summing amplifier for the output of the variable active filters.

### Trouble Shooting (Refer to Sheet 2 of Schematics)

Insure a good noise signal at the input of R98. Load all "ones" into the output latch, U7 as described in the Input Circuitry section and ground U7-15 to disable the nuke sound.

Measure the collector of Q14. It should be -3.5vdc. Next measure the collector of Q15. It should be -15vdc. With a scope, monitor Pin 6 of U43. It should be an 8v P-P waveform centered about ground. Next measure Pin 6 of U44, U45, U46 & U47. There should be no signal present.

Ground the junction of R113 & 114. Measure the collectors of Q14 & 15. They both should be about +5vdc. Now look at Pin 6 of U43. It should measure 10-12v P-P centered about ground. Pin 6 of U's 44 through 47 should all measure 4-6v P-P centered about ground.

### MUSIC (Refer to Block Diagram 3)

Various musical tones are played when a player receives either an extra ship or nuke, and at the beginning of new phases.

The circuitry involved consists of a two phase clock; a 12-bit divide-by-N counter, which determines the musical note to be generated; a music load control, used to reload the frequency select lines into the divide-by-N circuit; a music latch clock gating circuit which insures that the frequency select lines do not change during a load operation; a current controlled amplifier; three voltage switches and amplitude control networks.

### Two Phase Clock Generator

The two phase clock generator utilizes both halves of U19. It outputs two square-waves 90 degrees out of phase and their compliments. These four clock signals are used to clock U8-1, U9-1, U10-1, and U20-11 in sequence.

### 12-Bit Divide-By-N Counter

U8, 9 and 10 are 4-bit binary counters cascaded to form a 12-bit counter. When the "M Load—" signal goes low at Pin 9 of each counter and all three get clocked, the data appearing at pins 3 through 6 of U8, 9 and 10 gets preloaded into the counters. This data is referred to as the number N. After 4096-N clock pulses, the carry output of U8 (Pin 15) goes high causing the "M Load—" signal to go low and the data appearing at the counter inputs is again loaded and the sequence is repeated.

### Digital Music Output

The compliment of the "M Load –" signal at U20-9 is fed to pin 9 of U16. For every pulse appearing at U16-9 the "D Music +" signal at U16-5 toggles. This signal then would have one half the frequency of the incoming clock, and is always a square wave.

### Music Latch Clock Gating Circuit

This circuit is composed of U's 20 through 23. When the CPU wants to change the frequency select lines, it sends a pulse to connector J2-11. This pulse arrives at U20-3 and forces U20-6 low. This sets the "REQ" (request) signal at U22-9 low. If no M load operation is in progress, then U22-10 goes high. When MBCLK + goes from a low-to-high transition at U23-11, U23-9 goes high and the frequency select inputs at U5 & 6 get latched to the outputs of U5 & 6.

The second half of U23 is used to cancel the request (REQ -) after a short delay.

Because the M Load - signal can remain low indefinitely if all frequency selects are high, U21-9 will go high 4 clock cycles after a request (REQ -) has been made. This will preset U23-9 high, generating a M latch + signal thus canceling the request.

### Current Controlled Amplifier

The digital music signal from U16-5 is fed to a CCA, U48. For a technical description refer to the Loud Explosion Section.

### Amplitude Controls

There are three set of amplitude controls for the music circuit; C28, C29, C30, R132, R139, R140, R147, and R148. These different combinations give the music circuit more versatility by allowing different volume and envelope characteristics. For a technical description, refer to the Envelope discussion under the Loud Explosion Section.

### Voltage Switches

There are three voltage switches whose input come from U5 pins 5, 6 & 9. (These voltage switches consist of Q16 thru G19 and associated resistors.) For a technical description, refer to the Loud Explosion Section.

### Trouble Shooting

With a logic probe verify that U19 pins 5, 6, 8 and 9 all toggle.

To verify proper operation of the 12 bit counter (U8, U9 and I10), ground TP2 with a test lead. With a logic probe check pins 11 thru 15 on all 3 counters, they should all be toggling.

Next, move the grounded test load from TP2 to U20-Load all "ones" into U5 and U6 (refer to Input Control section). With a logic probe check pins 11 thru 14 on all 3 counters, they should all be high.

Using a second grounded test lead, ground U8-6. Verify that U8-11 is now low. Repeat this procedure for pins 11 thru 14 on U8, U9 and U10.

Remove the grounded test lead from U20-8 and place it on U5-12). The carry outputs of all three counters should be pulsing also check for activity at U20 pins 8, 9 and 12; and at U16 pins 5 and 9.

### OUTPUT AMPLIFIER (Refer to Block Diagram 1)

The output amplifier section consists of a preamp and volume pot driver U58 (TL081), main driver amp U51 (TL081) and speaker drive transistors Q22 and Q23. U50 drives the external volume pot located on the coin door and its associated cable. If little or no volume is heard, use an ohmmeter to meter the pot wires between J1-8 and J1-3. The resistance should vary as the pot is rotated. If the audio is at maximum volume regardless of the pot position, suspect an open lead between ground and the pot lead connected to connector J1-1. The final drive is a noninverting amplifier circuit containing U51, Q22, and Q23. Observe the waveform at the speaker wire which is the emitter junction of Q22 and Q23. If the upper half of any sound waveform appears clipped, suspect Q22. For the lower half, Q23 is the suspect. For no audio, meter Q22 and Q23 out of circuit and look for burned resistors R155 and R156. Also check diodes D9 and D10 at this time.





FIGURE ONE


### INPUT CONTROL CIRCUITRY


٥



BLOCK DIAGRAM ONE


### MASTER CLOCK






BLOCK DIAGRAM TWO

### MUSIC CIRCUIT




BLOCK DIAGRAM THREE

## EXPLOSIONS AND THRUST




BLOCK DIAGRAM FOUR

### FIRE SOUND




BLOCK DIAGRAM SIX



Ġ


BLOCK DIAGRAM FIVE

# OUTPUT CIRCUITRY




BLOCK DIAGRAM SEVEN

# WIDE-RANGE VOLTAGE CONTROLLED OSCILLATOR



BLOCK DIAGRAM EIGHT



BLOCK DIAGRAM NINE

Įi Ų

#### **SECTION 7**

### **TROUBLESHOOTING**

### UNIVERSAL BENCH TEST

### CONFIGURATION

The components depicted in figure A represent the integral elements and interconnects necessary to effectively bench test the Cinematronics vector display video game system. The configuration is universal in that the game logic board A, display assembly B, and the power supply D are consistent from game to game. Audio board C varies in design for each new game though maintaining the pinout of its input power molex plug. Player control ribbon cable 3 terminates at the player control panel elements of each game (i.e. Joystick, Fire & Thrust buttons, Coin Acceptor Mechanism, etc.)

### **POWER INTERCONNECTS**

The power supply D provides all voltages necessary for game operation.

Logic board drive is +5 volts ± 5% applied to pin 10 of the input power molex plug, & ground enters the logic board thru pin 4 to pins 1, 5, and 6. The logic board will free run in the game attract mode with proper power applied.

The audio board accepts +25 volts on pin4 and -25 volts applied thru pin 6 to pin 8. Ground enters pin 7 and is trace connected to speaker return pin 5. Pin 9 accepts +5 volts DC.

Power for the display is +25 volts thru pin 6 of its molex plug to pin 5 and -25 volts on pin 8. The CRT filament voltage of 6.3 V.A.C. enters the display electronics through pins 1 & 7 via a twisted pair of wires from the supply. A full wave rectified, unfiltered spot kill level of approximately +25 volts is applied to pin 14. The assembly is grounded thru pin 15 to pin 12.

### SYSTEM TEST CONSIDERATIONS

As previously mentioned, the logic board A will free run in the particular game attract mode solely with +5 volt applied. Ribbon cables 1 & 2 are output lines and can be removed without affecting the free-run mode. Ribbon cable 3 is an input line and can also be removed for test purposes while free running.

The audio board C can be effectively diagnosed with proper power applied and a speaker. The logic board generates most sounds by grounding various control lines through ribbon cable 2. The cable can be removed and game sounds can be generated by tying these lines low temporarily with a jumper wire. Refer to the appropriate audio board schematic and theory of operation section.

The display assembly cannot be powered up without data cable 1 from the logic board connected. With the cable open or improper data being fed from the logic board, the circuit breakers CB1 & CB2 on the power supply will trip indicating a load in excess of 3a being drawn from the +25 and -25 volt lines. Testing of the monitor requires a functional logic board. While troubleshooting a no display condition, it is recommended to remove the 8 pin molded female plug from the neck of the CRT to protect the phosphor on the tube face from being burned by a high intensity spot.

### TEST EQUIPMENT


For most test purposes, a wideband oscilloscope and a digital or analog multi-meter is adequate. Also, a tri-level logic probe for verifying the presence of digital information is recommended.

Testing and troubleshooting of the logic board is the least straightforward aspect of bench test. However, Cinematronics has developed a logic board exerciser to be used in conjunction with a signature analyser that allows effective troubleshooting & repair with a minimum knowledge of microprocessor theory and operation. The exerciser puts a 4 bit alphanumeric code on each IC leg of each chip on the CPU board which then can be probed & read with the signature analyser to verify proper operation. Contact the customer service department at Cinematronics for details.

### **TEST PROCEDURES**

The first step in effective bench testing is to review the system theory of operation included in the manual. Discussed are principles from the mathematical concept of vector systems to the actual hardware techniques employed in generating a vector video game display.

For specific troubleshooting procedures, refer to the symptom-remedy diagnostic chart included in the manual.



UNIVERSAL
BENCH TEST
CONFIGURATION

### MONITOR PROBLEMS

Here is a systematic guide to trouble shooting a monitor that blows breakers. Monitor must be connected to a good CPU. Check for burned components. The first thing we want to do is be able to power up the monitor without blowing breakers - then do trouble shooting.

POWER OFF. Unplug yoke from monitor board. Unplug socket from CRT. POWER ON.

If breakers blow: POWER OFF, See 1.

If breakers hold: Check outputs of -15v, +15v, and +5v regulators. Output must be within  $\pm 0.5$  volt tolerance.

A. Use O-scope to check deflection circuits for proper signal. 1mv/div time base is a good scope setting. Between DAC-80 output and input of Q101 or Q201, signal amplitude is about  $\pm 3$  volts peak. DC component should be less than  $\pm 200$  mv. Too much DC component will trip breakers. If signal into Q101/Q201 is good, problem is in transistorized deflection amps. With yoke disconnected, a good amp will put out an odd looking

"square wave", swinging between +25 volts. To check a bad deflection amp, check all transistors. Look for burned R118, R119, R113, R117 or R218, R219, R213, R217. R115, R116. R120, R121 may open with no burn marks. For test purposes, protection transistors Q106, Q107, Q206, Q207 may be removed from the circuit and amplifier can be powered up. Always replace protection transistors before returning monitor to normal service.

- 1. POWER OFF. Unplug heat sink wiring harnesses from monitor board. POWER ON. Breakers blow: POWER OFF See 2. Breakers hold: one or more of Q110, Q111, Q210, Q211 are shorted. Damage elsewhere is likely. Follow procedure at A.
- 2. Problem is most likely Video High Voltage module. Unplug from board and POWER ON. Breakers hold: replace or repair Video power supply. Breakers blow: Maybe a shorted tantalum capacitor. Or call us.

TABLE 7-1. TROUBLESHOOTING GUIDE

PROBLEM	PROBABLE SOLUTIONS
No Picture	Listen for audible "clatter" from the deflection yoke on the CRT neck. If the clatter is present, deflection circuitry is working and the problem is in the intensity circuit.
·	No high voltage.
	If game audio is present, the CPU board is functional and the problem is in the monitor. If the audio is distorted or absent, the CPU board is suspect. If CPU board is equipped with red led near the input power plug, verify that it flashes once when power is applied and remains off thereafter. If no LED, verify that C8 pin 6 is constantly low with a voltmeter.
	Check the neck of the CRT for a glowing filament. If there is no glow, check the brown & black twisted pair of the CRT plug for 6.3 volts AC.
	Be sure all connections to the CPU board and monitor are firmly seated.
	Connect a scope to the yellow wire leading to the CRT connector. Set brightness full clockwise. There should be an 80-100 volt DC base with pulses dropping down to a 40 volt level. If no pulses, probe IC7 pin 4 with a scope and observe data pulses. If present, check Q2 & Q3 with an ohmeter or transistor tester.
	Check cathode of D5 for a full wave rectified, unfiltered voltage signal floating at +25 volts.
	Check seating of CRT plug. Remove and probe with scope to verify presence of proper signals.
Narrow Line on Display	Check IC1.
	Check for open yoke windings with ohmeter.
	Check for bad solder & crimp connections to yoke wires.
	Verify continuity between display board and heat sunk power transistors Q110, Q210, Q111 and Q211.
	Check Q110, Q210, Q111, Q211 with ohmeter or transistor tester. Inspect solder connections on circuit board molex connector socket pins.
Half Picture	Left Half: Check Q206, 208, 210 Right Half: Check Q207, 209, 211 Top Half: Check Q107, 109, 111 Bottom Half: Check Q106, 108, 110

TABLE 7-1. TROUBLESHOOTING GUIDE (Continued)

PROBLEM	PROBABLE SOLUTIONS
	Check solder connections on heat sink molex plugs J3 & J4.
	Check diodes CR109, 110, 111 Check diodes CR209, 210, 211
	Check transistors Q105, Q205
	Check resistors R116, R216.
No Brightness Control	Check intensity pot R111 for open wiper or internal short. Check for open capacitor C17. Check for bad solder connections to R111.
Picture on Display Jitters	Replace analog switch IC1.
	Check size pots R109 and R209 for wiper noise by turning briskly while observing the screen. Readjust for proper screen size.
	Check for bad solder connections on R109 & R209.
	Check DAC IC101 & IC201 for bad solder connections.
	Insure that all molex connectors are properly seated.
Suspect High Voltage too high/too low	An accurate High Voltage meter will read close to $16KV$ if high voltage is good. Self-contained HV meters vary widely in accuracy. If $+90$ and $+400$ volts out of high voltage supply are good, chances are $16KV$ is good. If $+90$ or $+400$ volts are bad, repair or replace high voltage supply.
Dotted Display	Check IC-7 pins 2, 4. Verify proper operation of IC1. Check for proper +25 and -25 volts DC. Check operation of DAC's IC101 and IC201. On logic board, check I 8 pin 2 for pulses. Verify presence at analog switch.
No Audio	Check for open speaker coil. Check transistors 2N6292 and 2N6107 and nearby output components on audio board with ohmeter or transistor checker. Check 7815 and 7915 outputs. Check for open wiper on volume control mounted on inside of coin door.
	Refer to audio board theory of operation and troubleshooting guide.
	Replace F2 on logic board.

 TABLE 7-1. TROUBLESHOOTING GUIDE (Continued)

PROBLEM	PROBABLE SOLUTIONS
Coin Counter is Inoperative	Check 2N6292 transistor on logic board with ohmeter or transistor tester. Verify proper operation of A4 by grounding A4 pin 1. Coin counter should click.  Disconnect coin counter molex connector. Measure DC voltage on red wire. Meter should read +25 volts DC.
Gives No Credits	Tie E4 pin 12 to ground. If credits fail to appear, replace E4. If credits appear, disconnect logic board ribbon connector J3. Measure +5 volts on A4 pins 1 & 5. If missing, replace pull up resistor pack C2.  Alternately ground A4 pins 1 & 5. If credits appear, problem is in switches on coin door. Verify proper coin door microswitch operation.  Reconnect J3. Observe A4 pins 3 & 6 alternately while depressing microswitch lever on coin mechanism. Pins 3 & 6 should change states. Replace A4.  Replace F2 (74LS259) on logic board.
Player Control Button(s) Inoperative	Refer to player control schematic in APPENDIX.  Verify with ohmeter proper closure of player control leaf blade switches.  Remove J3 connector. Measure +5 volts on D4 - 1, 2, 3, 4, 12, 13, 14, 15. If missing, replace D4. Replace pull up resistor pack D2.  Measure +5 volts on C4 - 1, 2, 3, 4, 12, 13, 14, 15. If missing, replace C4. Replace pull up resistor pack C2.  Coin up a game and, with J3 disconnected, ground aforementioned pins on C4 & D4. If display responds problem is in continuity from J3 to player control switches.

### **SECTION 8**

### SUGGESTED PARTS FOR STOCK

The following parts fail most frequently:

### MONITOR LF13331 - Analog switch 2N5876 PNP output transistor 2N5878 NPN output transistor PNP driver transistor 2N5320 2N5322 NPN driver transistor 7406 IC inverter package - NPN transistor 140 volt BVceo 2N5550 7805 - +5 volt regulator IC 7815 - +15 volt regulator IC 7915 - -15 volt regulator IC CPU 74LS259/DM8334 — IC 8 bit latch 74LS32 - IC or gate DROM 1 - IC PROM 20101 A2 - IC RAM 256 x 4 **AUDIO** 2N6107 PNP output transistor 2N6292 NPN output transistor TL081/LF351 - IC op-amp CA3080 IC transconduct. 74LS377 IC octal D flip-flop (also used in CPU) The following parts don't fail frequently, but are not readily available local electronic supply houses: MONITOR DAC-80 - digital to analog converter

Masked ROMS — set of four contain game program

D ROMS (1-6) — custom made for CPU

- ALU

CPU

25LS181

ITEM NO.	CINEMATRONICS PART NO.	DESCRIPTION	MFGR. PART NO.	QTY.
		CABINET ASSEMBLY		
1	20-11382-01	Grill, Speaker		1
2 3	25-10552-01	Bolt, Carriage	3/16-11/2"	
3	25-10568-01	Washer, Flat	#10-1/2"	
4	71-10834-01	Speaker		1
5	25-10558-01	Nut, Hex	#10-24	3
6	25-10572-01	Washer, Lock	#10-Internal	3
7	87-11374-01	Harness, Main Wire		1
8	25-10580-01	Ty Rap w/eyelet		9
9	01-10505-01	Florescent Lamp		1
10	25-10566-01	Screw, Wood	#8- <sup>5</sup> /8"	2 2
11	26-10588-01	Florescent Lamp Fix		
12	01-10505-02	Florescent Lamp	Black Light	1
13	20-11401-01	CRT Mounting Rail		2
14	25-10558-01	Nut, Hex	ĺ	4
15	82-10842-21	Power Supply	Condor Mod.	
16	82-10842-31	Power Supply	Data Power Mod.	1
17	82-10842-40	Power Supply	Nat'l Power	
18	25-10553-01	Bolt, Carriage	3/16"	
19	15-11386-01	Backdrop		1
20	20-11376-01	Marquee, Plex Retain.	Upper	1
21	20-11377-01	Marquee, Plex Retain.	Lower	1
22	21-11384-02	Front Plexi	(Screened)	1
23	21-11385-02	Marquee Plexi	(Screened)	1
24	21-11395-01	Overlay		1
25	22-11394-01	Bezel, Cardboard		1
26	23-11152-01	Foam Tape	WO 5 1 1	1
27	25-10566-01	Screw, Wood	#8- <sup>5</sup> /8"	1
28	32-11381-01	Cabinet w/back	Reflextive	1
29	34-10903-01	Braid, Flat		
30	35-10618-01	Term, Ring Tongue	8	
31	87-11161-02	Harness, Coin Door		1
32	20-10862-01	Tongue, Coin Box		1
33	20-10864-01	Handle, Coin Box		1
34	20-10871-01	Coin Box	-	1
35	20-10872-01	Cover, Coin Box	2 / " 2 / "	
36	25-10990-01	Bolt, Carriage	3/16"-3/4"	
37	90-11388-01	Glass, Solar Bronze		1

ITEM NO.	CINEMATRONICS PART NO.	DESCRIPTION	MFGR. PART NO.	QTY.
		SUB-ASSEMBLY		
1	20-10896-11	Coin Door w/lamp		1
2	87-11161-02	Harness, Coin Door		1
3	25-10579-01	Ty Rap	X	<b>,</b>
4	25-10905-01	Cable Clamp <sup>3</sup> / <sub>16</sub> "		3
5 6		Wire 22 GA Wire 22 GA		
7		Wire 22 GA		
8		Wire 22 GA		
9		Wire 22 GA		
10	Wire 22 GA			
11	35-10614-01	Molex, Male Pin	02-09-2118	X
12 13	35-10615-01 41-xxxxx-01	Molex, Female Pin Conn, Molex	02-09-1118	X 1
14	87-11374-01	Mirror Upright	1	1
15	25-10561-01	Nut, Wire	Ideal #73B	1
16	34-10608-01	Wire 18 GA Red		1191/4"
17	34-10609-01	Wire 18 GA Blue		621/4"
18	34-10610-01	Wire 18 GA Black		188″
19 20	34-10906-01	Wire 22 GA Brn/Wt	Twisted	1461/4"
20	34-10908-01 34-11184-01	Wire 18 GA Orange Wire 18 GA Blk/Wt	Stripe	102½″ 43″
22	34-11185-01	Wire 18 GA Blk/Yel	Stripe	41 3/4"
23	34-11187-01	Wire 18 GA Red/Blk	Stripe	15"
24	34-11271-01	Wire 18 GA Blk/Wt	Twisted	1461/2"
25	34-11273-01	Wire 18 GA Green	_	85³/4″
26	34-11407-01	Wire 18 GA Yellow	621/4"	40.0
27 28	34-11408-01 34-11409-01	Wire 18 GA GA Wt/Grn	Cautan a	40 <i>"</i> 57 <i>"</i>
28 29	34-11409-01	Wire 18 GA Violet	Stripe	57″
30	34-11411-01	Wire 18 GA Wt/Blue	Stripe	57 <i>"</i>
31	34-11412-01	Wire 18 GA Brown	64"	_ ,
32	34-11413-01	Wire 18 GA Blu/Yel	Stripe	15″
33	35-10614-01	Pin Male Molex	02-09-2118	30
34	35-10615-01	Pin Female Molex	02-09-1118	23
35 36	35-10617-01 20-11378-01	Term, Female Q. Discon Player Cont'l Panel	.187032	$\frac{2}{1}$
37	22-11397-01	Control Pal Decal	Lexan	1
38	25-10559-01	Nut, Pal	WICO#19-0254-01	6
39	25-10574-01	Washer, Lock	#6 External	$\overset{\circ}{2}$
40	34-10596-01	Wire Buss	22 AWG	
41	37-11197-01	Button Asy. Short	WICO#19-0255-01	6
42	41-10654-01	Conn, Insulated	26 Cir	1
43	41-10646-01	Wafer Fric Lock, 3CIR		1

ITEM NO.	CINEMATRONICS PART NO.	DESCRIPTION	MFGR. PART NO.	QTY.
44 45 46 47 48 49 50 51	80-10840-01 87-11389-01 34-10597-01 34-10598-01 34-10600-01 34-10602-01 34-10603-01 34-10606-01	Distribution P.C.B. Harness, Cnt'l Panel Wire 22 GA Black Wire 22 GA Green Wire 22 GA Yellow Wire 22 GA Violet Wire 22 GA Orange Wire 22 GA Gray Wire 22 GA Red		1 1 9 <sup>3</sup> / <sub>4</sub> " 13 <sup>1</sup> / <sub>4</sub> " 12 <sup>3</sup> / <sub>8</sub> " 10 <sup>5</sup> / <sub>16</sub> " 14 <sup>1</sup> / <sub>8</sub> " 8 <sup>23</sup> / <sub>32</sub> " 11 <sup>1</sup> / <sub>4</sub> "
		MECHANICAL ASSEMBLY	·	
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24	20-10522-01 25-10563-01 45-10719-01 66-10822-01 87-10873-01 87-10874-01 20-10525-01 25-10563-01 25-10571-01 38-10626-01 87-10847-01 87-10848-04 38-10633-02 20-10528-01 20-10528-01 20-10869-01 25-10564-01 25-10568-01 25-10569-01 38-10628-02 82-10841-01 82-111083-03	Heat Sink Machine Screw Washer, Greaseless Transistor Transistor Harness, Long H.S. Harness, Short H.S. Mounting Plate  Machine Screw #6 Internal Logic Board Assy. Ribbon Cable 16 Pin Ribbon Cable 34 Pin Monitor Assembly Chassis Bracket, CRT Mounting Bracket, CRT Mounting Screw, Sheet Metal Screw, Sheet Metal Washer, Flat Washer, Flat Display Board Assy. Power Supply, Video Power Supply, Video	2 6-32-1/2PNHDPH PNP 2N5876 NPN 2N5878  Logic & Audio Brds 6-32-PNHDPH 9  Audio to Logic W/3 Conn.  Display Bd Frame Left Hand Right Hand #6-1/2" Hex Hd #10-1/2" Hex Hd #10-1/2" #10-1" Multi-Inten Mod Keltron PTK HV Module	4 2 2 1 1 1 9 1 1 1 1 1 1 1 1
		LOGIC P.C.B. ASSEMBLY		
1 2	01-10500-01 35-10616-01	Tubing, Teflon Test Points	22 GA Thin	25 <i>'</i> 6

ITEM NO.	CINEMATRONICS PART NO.	DESCRIPTION	MFGR. PART NO.	QTY.
3	35-10965-01	Jumpers, 16 Pin		2
4	36-10619-01	Socket, Dip 14 Pin		2
5	36-10620-01	Socket, Dip 16 Pin		4
6	36-10621-01	Socket, Dip 25 Pin		7
7	37-10625-01	7 Pole Dip Switch	JS8722-01	1
8	38-11405-01	E-Prom Kit (2732)	Solar Quest	4
9	41-10652-01	Male Header 16 Pin	609-1622M	1
10	41-10653-01	Male Header 26 Pin	609-2622M	1
11	41-10654-01	Male Header 34 Pin	609-3422M	1
12	41-10655-01	Conn. Molex 12 Cir	09-18-5127	1
13	44-10667-01	IC	2101A2	3
14	44-10671-01	IC	7425	1
15	44-10675-01	IC	74265	1
16	44-10676-01	IC	25LS181	3
17	44-10677-01	IC	74LS00	4
18	44-10678-01	IC	74LS00	4
19	44-10679-01	IC	74LS00	3
20	44-10680-01	IC	74LS00	1
21	44-10681-01	IC	74LS10	3
22	44-10682-01	IC	74LS27	3
23	44-10683-01	IC	74LS32	4
24	44-10684-01	IC	74LS75	2
25	44-10685-01	IC IC	74LS85	3
26	44-10686-01	IC	74LS86	1
27	44-10687-01	IC IC	74LS107	7 4
28	44-10688-01	IC IC	74LS151 74LS157	8
29 30	44-10689-01 44-10690-01	IC IC	74LS157 74LS163	9
31	44-10691-01	IC IC	74LS163	1
32	44-10692-01	ic ·	74LS104	9
33	44-10693-01	IC	74LS257	$\tilde{3}$
34	44-10694-01	IC	74LS259	1
35	44-10695-01	IC	74LS298	2
36	44-10696-01	ic	74LS377	6
37	44-10697-01	ic	74LS393	2
38	44-10698-01	ic	74800	2
39	44-10699-01	IC	74S02	1
40	44-10700-01	IC	74S04	2
41	44-10701-01	IC	74S08	1
42	44-10702-01	IC	74S10	1
43	44-10703-01	IC	74S32	2
44	44-10704-01	IC	74S113	2
45	44-10705-01	IC	74S158	1
46	44-10706-01	IC .	74S182	1
47	44-10707-01	IC, Drom 1	2085	1
48	44-10708-01	IC, Drom 2	2086	1

ITEM NO.	CINEMATRONICS PART NO.	DESCRIPTION	MFGR. PART NO.	QTY.
49	44-10709-01	IC, Drom 3	2087	1
50	44-10710-01	IC, Drom 4	2087	1
51	44-10711-01	IC, Drom 5	2089	1
52	44-10712-01	IC, Drom 6	2090	1
53	53-10726-01	Resistor, ½W 5% C	100 OHM	1
54	53-10720-01	Resistor, 1/4W 5% C	330 OHM	$\frac{1}{2}$
55	53-10731-01	Resistor, <sup>1</sup> / <sub>4</sub> W 5% C		1
56	53-10734-01	Resistor, <sup>1</sup> / <sub>4</sub> W 5% C	470 OHM	
57	53-10734-01	Resistor, <sup>1</sup> / <sub>4</sub> W 5% C	1K OHM	12
58	53-10736-01		2.2K OHM	$\frac{1}{2}$
59	53-10746-01	Resistor, ½W 5% C	10K OHM	2
		Resistor, ½W 5% C	SOK OHM	1
60	53-10762-01	Resistor, 1/4W 5% C	560K OHM	1
61	53-10779-01	Resistor, Dip Pak	1K OHM	2
62	63-10783-01	Capacitor, Disk	.02MF 50V	58
63	63-10785-01	Capacitor, Disk	680PF 100V	1
64	63-10808-01	Capacitor, Dip Tant	3.3MF 35V	1
65	63-10810-01	Capacitor, Dip Tant	22MF 35V	1
	63-10995-01	Or Capacitor, Elect Rad	100MF 50V	1
66	65-10811-01	Diode	1N914B	2
67	65-10814-01	L.E.D	TIL220	1
68	66-10816-01	Transistor	2N3904	2
69	66-10825-01	Transistor	2N6292	1
70	69-10833-01	Crystal, 20 MHZ		1
71	80-10837-01	P.C Board		1
72	34-10594-01	Wire 30 GA	Blue Kynar	2′
		DISPLAY P.C.B. ASSEMBLY		
1	25-10582-01	Shrink Tubing	3/16" Roll Stock	14"
2	25-10582-01	Shrink Tubing	3/16" 2" Lengths	2
2 3	25-10582-03	Shrink Tubing	3/16" 3" Lengths	2
4	34-10608-02	Wire 18 GA Red	9" Lengths	$\frac{2}{2}$
5	35-11205-01	Terminal, Ring Tongue	22GA (A3651-194)	1
6	36-10622-01	Socket, CRT	. = =	î
7	01-10501-01	Tubing, Teflon	22 GA Thin	.5′
8	01-10506-01	Neon Lamp	NE-2	2
9	20-10523-01	Heat Sink, Thrmaloy	2230B	6
10	20-10524-01	Heat Sink, Thrmaloy	6045B	1
111	23-10548-01	Thermal Compound	DOW 340	
12	23-10996-01	Adhesive, Silicone	RTV	
13	15-10579-01	TV Raps	T-18R	2
14	25-10596-01	Wire 22 GA/TC	1 1011	_
15	34-10604-02	Wire 22 GA Brown	4" Lengths	1
16	34-10604-06	Wire 22 GA Brown	3" Lengths	2
17	34-10604-07	Wire 22 GA Brown	2½" Lengths	1
18	34-10608-02	Wire 18 GA Red	9" Lengths	$\frac{1}{2}$
	01 10000 02	viic 10 oil fied	/ Lengins	۷

ITEM NO.	CINEMATRONICS PART NO.	DESCRIPTION	MFGR. PART NO.	QTY.
19	34-10609-02	Wire 18 GA Blue	10" Lengths	1
20	34-10610-03	Wire 18 GA Black	5½″ Lengths	1
21	35-10613-01	Pin, Molex Sldr TL	02-09-2134	8
22	36-10620-01	Socket, 16 Pin		8 2 2
23	36-10621-01	Socket, 24 Pin		2
24	41-10654-01	Male Header 34 Pin		1
25	41-10660-01	Conn, Molex 15 Cir	03-09-1152	1
26	41-10661-01	Conn, Molex 6 Cir	09-18-5061	1
27	41-10662-01	Conn, Molex 6 Cir	09-18-5062	1
28	41-10663-01	Conn, Molex 6 Cir	09-18-5069	2
29	44-10669-01	IC	7406	1
30	44-10672-01	IC	7805C	1
31	44-10673-01	IC	7815C	1
32	44-10674-01	IC	7915C	1
33	44-10714-01	IC & (See Note #1)	DAC 80 (bbrown)	2
34	44-10715-01	IC (See Note#2)	LF 13331	1
35	44-10718-01	IC	TL081P	2
36	51-10720-01	Pot, Trim	100 OHM	2 2 2
37	51-10721-01	Pot, Trim	5K OHM	2
38	51-10722-01	Pot, 10K	JA1N056103UA	1
39	53-10723-01	Resistor, ½W 5%C	15 OHM	2 2
40	53-10724-01	Resistor, 1/4W 5% C	33 OHM	2
41	53-10725-01	Resistor, 1/4W 5% C	47 OHM	6
42	53-10726-01	Resistor, ½W 5% C	100 OHM	4
43	53-10729-01	Resistor, 1/4W 5% C	200 OHM	2
44	53-10731-01	Resistor, 1/4W 5% C	330 OHM	1
45	53-10732-01	Resistor, ½W 5% C	470 OHM	5
46	53-10733-01	Resistor, ¼W 5% C	820 OHM	4
47	53-10734-01	Resistor, ½W 5% C	1K OHM	2
48	53-10736-01	Resistor, ½W 5% C	1.8K OHM	1
49	53-10738-01	Resistor, ½W 5% C	2.2K OHM	1
50	53-10740-01	Resistor, ½W 5% C	3K OHM	3
51	53-10744-01	Resistor, ½W 5% C	5.6K OHM	2
52	53-10746-01	Resistor, ½W 5% C	10K OHM	4
53	53-10758-01	Resistor, ½W 5% C	68K OHM	$\frac{1}{4}$
54	53-10766-01	Resistor, ½W 5% C	47 OHM	4
55	53-10767-01	Resistor, ½W 5% C	2.2K OHM	1
56	53-10768-01	Resistor, ½W 5% C	8.2K OHM	4
57	53-10769-01	Resistor, ½W 5% C	10K OHM	1
58	53-10770-01	Resistor, 1W 5% C	2.7 OHM	12
59	53-10771-01	Resistor, 1W 5% C	360 OHM	2
60	53-10773-01	Resistor, 2W 5% C	100 OHM	1
61	53-10774-01	Resistor, 3W 5% C	.18 OHM	4
62	53-11204-01	Resistor, ½W 1% F	1.43K OHM 2.1K OHM	1
63	53-10777-01	Resistor, ½W 1% F	10K OHM	1 2
64	53-10778-01	Resistor, 1/4W 1% F	0 OHM	15
65	53-11123-01	Resistor, (Unprepped) Resistor, <sup>1</sup> / <sub>4</sub> W 5% C	13K OHM	15
66	53-11367-01	The sistor, 74 VV J N C	13K OHM	1

ITEM NO.	CINEMATRONICS PART NO.	DESCRIPTION	MFGR. PART NO.	QTY.
67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86	63-10781-01 63-10784-01 63-10799-01 63-10802-01 63-10805-01 63-10807-01 63-10943-01 63-10948-01 65-10811-01 65-10815-01 66-10816-01 66-10819-01 66-10820-01 80-10902-01 87-11387-01	Capacitor, Disk Capacitor, Elect. AX Capacitor, Elect. AX Capacitor, Film Capacitor, Dip Tant Capacitor, Film Diode Diode Transistor Transistor Transistor Transistor Transistor Transistor P.C.Board Harness, Multi-Inten.  NOTE #1: Beckman DAC and Burr-Brown DAC are not directly interchangeable. When Beckman 7580 vs. DACS are used, substitute as follows: 1. Change Resistor, 1/4W 1% film 1.43K OHM 53-10776-01 to Resistor, 1/4W 1% film 11.0K OHM 53-11004-01 2. Change Resistor, 1/4W 1% film 2.1K OHM 53-10777-01 to Resistor, 1/4W 1% film 7.5K OHM 53-11005-01  NOTE #: In the absence of the analog switch (44-10715-01), substitute the following items:  P.C. Board Ribbon Cable 87-10986-01 1 Socket, 16 Pin 36-10620-01 1 IC 44-10990-01 HI-5045 1 0 or 44-10991-01 HI-5045 1 Diode 65-10992-01 1N5231 1 Resistor, 1/4W 5% C 53-10734-01 1K OHM 2 Capacitor, Elect. Rad. 63-10993-01 47MF 50V 2	.005MF 50V .1MF 50V 47MF 50V .33MF 35V .022MF 200 V .47MF 35V 2.2MF 35V 4.7 MF 35V .1MF 100V 1N914B 1N4003 2N2102 2N3904 2N3906 2N5320 2N5322	2 6 2 1 3 6 1 2 11 31 4 3 2 7 2 4 1 1
87	63-10784-01	Capacitor, Disk	.1MF 50V	1

ITEM NO.	CINEMATRONICS PART NO.	DESCRIPTION	MFGR. PART NO.	QTY.
		MULTI-LEVEL INTENSITY ASSEMBLY		
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26	41-10654-01 41-10656-01 44-10669-01 44-10670-01 44-10696-01 51-11403-01 53-10738-01 53-10746-01 53-10748-01 53-10779-01 53-10799-01 53-10923-01 53-10925-01 53-10925-01 53-10927-01 53-11313-01 63-10780-01 63-10784-01 63-10784-01 63-11371-01 65-10811-01 65-10821-01 80-11375-01	Connector, 34 Pin Connector, 9 Pin IC IC 74LS377 Pot, 50K OHM Trim Resistor, ½W 5% C Resistor, ¼W 5% C Capacitor, ¼W 5% C Capacitor, Disk Capacitor, Disk Capacitor, Disk Capacitor, Disk Capacitor, M.Film Diode Diode Diode Transistor P.C.B. (Board only)	Wafercon 7406 7414 1 3386-T1-503 470 OHM 2.2K OHM 10K OHM 15K OHM 15K OHM 1K OHM 4.3K OHM 36K OHM 91K OHM 91K OHM 91K OHM 470PF 1MF 50V 100MF 35V .001MF 50V 1N914 1N5236 MR818 2N5550 Multi-Inten.	1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
		AUDIO P.C.B. ASSEMBLY		
1 2 3 4 5	20-10520-01 20-10521-01 23-10548-01 25-10556-01 25-10570-01 25-10974-01	Heat Sink, Therm Heat Sink, Therm Thermal Compound Hex Nut Lockwasher Machine Screw	6071B 6072B DOW 340 4-40 #4 Internal 4-40-3/8PNHDPH	4 6 6
7 8 9 10 11 12 13	41-10652-01 41-10656-01 44-10670-01 44-10673-01 44-10674-01 44-10686-01	Header, 16 Pin Conn, Molex 9 Cir IC IC IC IC	609-1622 M 09-18-5094 7414 7815 7915 74LS02 74LS86	1 1 2 1 1 1

ITEM NO.	CINEMATRONICS PART NO.	DESCRIPTION	MFGR. PART NO.	QTY.
14	44-10687-01	IC	74LS107	2
15	44-10690-01	IC	74LS163	6
16	44-10691-01	IC	74LS164	5
17	44-10696-01	iC	74LS377	3
18	44-10697-01	IC	74LS393	3
19	44-10700-01	IC	74S04	1
20	44-10704-01	IC	74S113	1
21	44-10713-01	IC	CA3080E	4
22	44-10713-02	IC (Special)	CA3080A	2
23	44-10716-01	IC (Special)	LM555	2
24	44-10718-01	IC	TL081P	12
25	44-10913-01	IC	LM566	1
26	44-11028-01	IC IC	74LS74	5
27	44-11031-01	IC (Sub for LS163)	74LS161	0
28	53-10726-01	Resistor, ½W 5% C	100 OHM	4
29	53-10727-01	Resistor, ½W 5% C	150 OHM	2
30	53-10729-01	Resistor, <sup>1</sup> / <sub>4</sub> W 5% C	200 OHM	4 .
31	53-10723-01	Resistor, ½W 5% C	330 OHM	2
32	53-10731-01	Resistor, <sup>1</sup> / <sub>4</sub> W 5% C	1K OHM	19
33	53-10737-01	Resistor, 1/4W 5% C	2K OHM	4
34	53-10737-01	Resistor, ½W 5% C	2.7K OHM	12
35	53-10733-01	Resistor, ½W 5% C	4.7K OHM	23
36	53-10745-01	Resistor, ½W 5% C	8.2K OHM	3
37	53-10745-01	Resistor, 1/4W 5% C	10K OHM	4
38	53-10740-01	Resistor, <sup>1</sup> / <sub>4</sub> W 5% C	12K OHM	11
	53-10747-01	Resistor, <sup>1</sup> / <sub>4</sub> W 5% C	15K OHM	2
39 40	53-10748-01	Resistor, <sup>1</sup> / <sub>4</sub> W 5% C	20K OHM	6
	53-10749-01	Resistor, 1/4W 5% C	22K OHM	2
41 42	53-10750-01	Resistor, <sup>1</sup> / <sub>4</sub> W 5% C	24K OHM	1
43	53-10751-01	Resistor, <sup>1</sup> / <sub>4</sub> W 5% C	30K OHM	1
	53-10753-01	Resistor, <sup>1</sup> / <sub>4</sub> W 5% C	39K OHM	10
44	53-10754-01	Resistor, <sup>1</sup> / <sub>4</sub> W 5% C	47K OHM	
45 46	53-10756-01	Resistor, <sup>1</sup> / <sub>4</sub> W 5% C	1M OHM	2 5
1	53-10765-01	Resistor, 1/4W 5% C	1.5 OHM	1
47 48	53-10763-01	Resistor, 1/4W 5% C	390 OHM	5
48	53-10914-01	Resistor, 1/4W 5% C	6.8K OHM	1
50	53-10921-01	Resistor, 1/4W 5% C	18K OHM	1
50	53-10925-01	Resistor, 1/4W 5% C	36K OHM	1
	53-10926-01	Resistor, 1/4W 5% C	51K OHM	5
52	53-10928-01	Resistor, 1/4W 5% C	100K OHM	10
53	53-10928-01	Resistor, 1/4W 5% C	200K OHM	2
54	53-10931-01	Resistor, 1/4W 5% C	240K OHM	1
55	53-10932-01	Resistor, 74W 5% C	270K OHM	1
56	53-10934-01	Resistor, 74W 5% C	300K OHM	1
57		Resistor, 1/4W 5% C	360K OHM	1
58	53-10935-01	Resistor, 74W 5% C	390K OHM	2
59	53-10936-01	Resistor, 1/4W 5% C	11K OHM	1
60	53-11004-01 53-11002-01	Resistor, 74W 576 C Resistor, 5W	.51 OHM	2
61	J3-1100Z-01	116313[0], 344	.01 011111	

ITEM O	CINEMATRONICS PART NO.	DESCRIPTION	MFG <b>R</b> . PART NO.	QTY.
62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93	53-11312-01 53-11314-01 53-11368-01 63-10780-01 63-10782-01 63-10785-01 63-10788-01 63-10940-01 63-10941-01 63-10943-01 63-10949-01 63-10949-01 63-10950-01 63-10950-01 63-11127-01 63-1393-01 63-1393-01 65-10811-01 65-10813-01 66-10824-01 66-10825-01 69-10833-01 80-11366-01	Resistor, ½W 5% C Resistor, ½W 5% C Resistor, ½W 5% C Resistor, ½W 5% C Capacitor, Disk Capacitor, Disk Capacitor, Disk Capacitor, Disk Capacitor, Disk Capacitor, Disk Capacitor, Elect. Rad. Capacitor, Elect.Rad. Capacitor, Elect.Rad. Capacitor, Film Cap	120K OHM 10M OHM 13K OHM 75K OHM 470PF 50V .005MF 50V .01MF 50V .1MF 50V 680PF 100V 25MF 50V .001MF 50V 2.2MF 35V 3.3MF 35V 4.7MF 35V .01MF 100V .1MF 100V .22MF 100V .33MF 100V .47MF 100V .47MF 100V .47MF 100V .1MF 50V 330PF 50V .001MF 50V 1N914B 1N4003 Plast 1N5240 10V 2N3904 2N3906 2N6107 2N6292 20MHZ	2 2 1 2 3 1 2 4 1 5 1 3 1 1 1 2 6 2 2 1 2 3 2 1 2 1 2 1 1 1 1 1 1 1 1 1 1


### APPENDIX A

Assembly Drawings
Schematics
and
Wiring Diagrams


### TABLE OF CONTENTS

# ASSEMBLY DRAWINGS SCHEMATICS AND WIRING DIAGRAMS


- 1. CABINET DRAWING
- 2. WIRE LIST MIRROR UPRIGHT
- 3. POWER SUPPLY PINOUT ILLUSTRATION
- 4. CONDOR POWER SUPPLY SCHEMATIC
- 5. NATIONAL POWER TECHNOLOGY POWER SUPPLY SCHEMATIC
- 6. PLAYER CONTROL AND COIN MECHANISM WIRING DIAGRAM
- 7. CPU BOARD SCHEMATIC
- 8. CPU BOARD MAJOR COMPONENT DRAWING
- 9. CPU BOARD ILLUSTRATION
- 10. DISPLAY BOARD SCHEMATIC
- 11. DISPLAY BOARD ASSEMBLY DRAWING
- 12. MONITOR ASSEMBLY DIAGRAM
- 13. DISPLAY BOARD CONNECTORS AND ADJUSTMENTS DRAWING
- 14. HEAT SINK ILLUSTRATION
- 15. HEAT SINK ASSEMBLY
- 16. AUDIO BOARD SCHEMATIC
- 17. AUDIO BOARD ASSEMBLY DRAWING
- 18. 64 LEVEL INTENSITY SCHEMATIC
- 19. 64 LEVEL INTENSITY ASSEMBLY DRAWING





r				<u> </u>	<b>V</b>	<u> </u>	<b>⋖</b>
	C3AOnday 3.vc	AEMARK VOLUME SEE NOTE VOLUME		NOT USED NOT USED REF GND REF GND NOT USED NOT USED		96"LONG W/PLUG S WRE TWST NOT USED REF ASE REF ASE	REF 6.3 VAC REF 6.3 VAC REF 6.3 VAC \$2000
-	REVISIONS	45 /4 85 % 85 % 65 /4	4 7 w 4 0 m) 0 m) 4 4 4	.0	ıΩm		
	OF SCHIPTION	<del>-</del>	և <u>ը և <b>ը</b> և և</u>	<b>4</b> € 11.	п QQ	.>	DWG TITLE
	9EV	X 0 1 0 1 0	ww a	ω -	<u></u>	18×3	DATE DOWG
***	\ <del>\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ </del>	<u> </u>	GRAY VIOLET BLACK BLACK WHT/BLU ORANGE	BROWN BLK/WHT BLK/YEL	ORANGE BLU/YEL RED/BLK	1-	WHITY WHITY WHITY BRAWN B CONFECT BELEASE BROJECT BELEASE BROJECT BROJ
		H10-1 SPEAKER H10-5	HIO-4 SPEAKER HR-8 HR-8 HR-6 HR-6	H 2 - 2 H 2 - 2 H 2 - 2 H 3 - 2 H 3 - 2 H	H2-10 H9 BLK H2-5	H8 COM H8 COM H4-1 H4-3 H4-4	H H H H H H H H H H H H H H H H H H H
2		10111	1 1 1 1 1 1 1 1 1 4 4 4 4 4 4 4 4 4 4 4	I I I I I I I I I I I I I I I I I I I	H6-9 H6-10 H6-11 H6-12 H8 COM H8 N.O.	H9 GRN H9 WHT H9 BLK H10-1 H10-2 H10-4	1 1 10 - 0 1 1 10 - 0 1 10 - 0 1 10 - 0 2 10 - 0 2 10 - 0 2 10 - 0 2 10 - 0 3 10 - 0
		CONNECTOR	MOLEX 03-09-	H-6 MOLEX 03-09-		LINE CORD H 9 COIN DOOR H 10 H 10 MOLEX	1093 1093 1093 N/Q (NOTE NN ECT 59-:::8
m	REMARKS	TWST PAIR	TWIST PAIR 6.3 VAC TWIST PAIR 6.3 VAC SPOT KILL	+ + 1 1 + + + 5 M M M M M M M M M M M M M M M M M M M	10 H C T C	REF 6 REF 6 REF 6 ROA COA	REF SPOT
	PIN LENGTH	MX 6934 MX 7234 MX 7234 MX 7234	X 22/4	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$		пгп п %	SANDER END OTHER END OFFEMALE FEMALE 3
	AWG	<b>ចំ</b> លិ <i>ច</i>	<u> </u>	$m$ $\tilde{a}$ $\tilde{a}$ $m$ $\tilde{a}$ $\tilde{a}$ $\tilde{a}$	<u> </u>	ã	200 4.
	COLOR	SCACK STITE STITE SREEN STITE STIT STIT	WHITE RED/BLK BROWN WHITE BROWN WHITE	KEU GRAY BLUE BLUE CRANGE ORANGE	BLACK BLK/WHT BROWN	RED WHITE BLUE BLUE 3LK /YEL	CKANGE YELLOW YELLOW OLICA CTION CTION CTION CTION
4	10	LAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAA	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	0 - 0 H H H H H H H H H H H H H H H H H	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	TTT L adom 3 Ladom 1	10 12-0 CKAN 15 12-6 YELL 15 12-10 BLA 17 CONECTION 76 ENGTHS 48 3110 1 PEA VCH WELSTOFTER
	TARY THE PROPERTY SING AND IS RODUCED OR ROUT WRITTEN	1111 1111 1111 1111 1111 1111 1111 1111 1111			H2-11-12-12-13-13-13-13-13-13-13-13-13-13-13-13-13-	TITITITI TANANANANA TITITITI	റഹരി <sup>ш</sup>
	PROPRIETARY THIS DOCUMENT IS THE PROPERTY OF CINEMATIONNICS INC. AND IS NOT TO BE REPRODUCED OR DISTRABILED WITHOUT WRITTEN AUTHOR ZATION OF CHRWATRONICS	POWER SUPPLY 'AGLEX C3-09-1042		× 6 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 T	MOLEX 03-09- 233	A M = MALE  A NN = WAR  1. TWISTED  NOTES UNITS OF 1
1				<u> </u>	<b>A</b>	w · · · · · · · · · · · · · · · · · · ·	4 · sa · said





Ċ




















APPROVED		TC TICN AREA D	9		-							)	ပ			47		4	<b>.</b>					8									 El Cajon	07076	New Control	
DATE	-	SCHMTC LOCATION SHT-AREA	1-A6			0	c	)	e)		6 -A6					5-47		1-84				.1											ONICS INC	MEMORY	DWG DWG NO.	1 1 1 1
REVISIONS DESCRIPTION	_1	FROM /TO IC- PIN NO.	70 04-14	O		CONN. 43-K5	(	FROM	DISPLAY PCB	T0	CONN. JR-16					TO A8-8	86-9	FROM FR-4	FROM FR-5	FROM FR-7	FROM FR-9	FROM FR-12											CINEMATE	DWG TITLE 1/6	MODEL HO DWG DWG	2 0 1430
REV DESCI	CONNECTOR J4	FUNCTION	PRIMARY INPUT 13		PRIMARY INPUT IS		אייאושוא יארטיי	XDAC OUTPUT			A) THOM YARMAG	F IDINI / WIND	NC	o v		EXTERNAL	HIGH CUTPUT	CUTPUT Ø	OUTPUT !	OUTPUT 3	OUTPUT 4	OUTPUT 7											ONAWH BY DATE	PROJECT ENGR DATE	DO NOT SCALE DWG TOLERANCE UNLESS OTHERWISE SPECIFIED	PROJECTION SCALE
		PIN NO.	_		જ	ķ	n	4			ď	١	۵	r 0	ο σ	, 0		=	ď,	5 4	(5)	9	_										MATERIAL		:HSH:	
		SCHMTC LCCATION SHT-AREA			97-/				1-86						90-	) t									1-05											
	<b>6</b> 5	FROM /TO IC - PIN NO.			70 E4 - 4	70 E4-1	70 54-2	TO E4-13	TO D4 -1	TO 04.2	70 04-3	70 D4-12	TO D4- (3	4 40 04 14	70 04-15	10 C4-12	TO C4-3	To C4-4	70 C4-15	TO C4-14	CONN. U4-1	TO C4-13	CONN 04-5	10 CT-12	TO 44-5		TO A4-									
	CCHNECTOR	FUNCTION	NC	<del>ا</del> ک	SECONDARY INPUT &	SECONDARY INPUT 3	SECONDARY INPUT &	SECONDARY INPUT 6	PRIMARY INPUT 3	PRIMARY INPUTE	PRIMARY INPUT!	PRIMARY INPUT 7	PRIMARY INPUT 6		PRIMARY INPUT 4	PRIMARY INPUT IS		PRIMARY INPLIT 8	PRIMARY INPUT IZ	A) THON YOUNG		PRIMARY INPUT 14	1. O	FRIMARY INFO IS	COIN SWITCH	(VORMALY CLOSED)	COIN SWITCH	(NOWWALT OFFN)								
		PIN NO.		.v	30	4	ر د	٦ و	~ ~0	<u> </u>	9 :	= 10	/3	4	J :	0 5	160	6/	20	ā	ì	22		0	24		S V	<i>و</i> س								
		SCHMTC LOCATION SHT-AREA	6-44				6-A5			6 A6		6-03	6-A6	67-9						6-C6	}	6-A4					6-45			6-46						
	TOR J.R.	FRCM /TO IC - FIN NO.	FROM M2-9	FROM ME- 19	FROM ME-2	FROM MR-6	FROM PZ-9	FROM PR-17	FROM PE-6	FRCM 52-9	FROM 32-19	FROM JZ-3 FROM JZ-3	FROM 32-2	FROM JZ-11	i i	FROM DISPLAY P.C.B.	70	CONN. J4-4		FROM HB-13	1	FKOM M2-16	:	FIKCM 112-12	FROM MZ-15	FROM MR-5	FROM PR-16	FROM PR-IZ	FROM PR-5	FROM SR-16	FROM SZ-12	FROM S2-5				
Approximate to the second seco	CONNECTOR	FUNCTION	YDAC BIT /	YDAC BIT Ø	JOAC BIT 3	817	B17	YDAC BIT 7	5 13	10AC 81T 9	YDAC BIT 8	YDAC BIT ID	YDAC BIT II	BRIGHT	GND	KDAC CUTPUT			GND	INITIALIZE SWITCH	GND GND	XDAC BIT &	GND	XDAC BIT I	XOAC BIT &	XDAC BIT3		XDAC BIT 5 XDAC BIT 6	8/T 7	8/T B	ë d	XOAC BIT IS				
		PIN NG		- «I	m	4	νn ·	ء ا ي	~ 00	Q/	ē .	= 2	i w	4	in :	9/			1	6/	n C	13	22	£ 0.3	65 25	9,	27	79 0 0 0	) M	10	32	ი ს ი 4				
	<u>-</u> -)	SCHWITC CCATION SHT-AREA			/-C4						6-03								0				-						r							
	CONNECTOR	FKOM / TO TC = PIN NO.			FROM COLLECTOR	SF Q1					FROM A2-3.6										60			Ω	NO NOTICE CONTICE ON	KD WITH	PIN NG. I CALLED COT									PECIFIED
PROPRIETARY	THIS DOCUMENT IS THE PROPERTY OF CINEMATRONICS INC. AND IS NOT TO BE REPRODUCED OR DISTRIBUTED WITHOUT WRITTEN AUTHORIZATION OF CINEMATRONICS	FUNCTION	278	) Y C	COIN COUNTER		(FEMALE) (ND	GND	פאס	) V	LED CATHODE	In V	. S						**		36				CONNECTO	C.FU. ECAKD WITH	PIN NC. 7									NOTES: UNLESS OTHERWISE SPECIFIED
	OF CH NOT DISTRI	ο 2 d 2 Z d 2 Z d	<u>:</u>   -	۷، -	(ر:			ā,	» >	- xc	(1)	5 :		!					<u> </u>	-									a management	١					LLONG C	


A7-7





5












MONITOR ASSEMBLY (KELTRON)


38-10633-02


MONITOR ASSEMBLY (PTK)


38-11207-02





CONNECTORS AND ADJUSTMENTS DISPLAY P.C.B.
















| 19 | SEPTE-MSER | 1981 | 19 | SEPTE-MSER | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 | 1981 |

2 CHECK TRANSISTOR AND CARNCITOR LEGEND ABOVE TITLE BLOCK, AT RIGHT 2 CAPACTOR VALUES ARE IN MICKO, FARADS

ALL PESISTOR MALIES ARE IN DHMS, 1/4 WAT, 5% CARBON, NOTES LUNESS OTHERWISE SPECIFIED







7.4

